

# Color Camera Module

# **Technical Manual**



FCB-IX11A/IX11AP

# **Table of Contents**

| Features 3                                 |      |  |  |  |  |
|--------------------------------------------|------|--|--|--|--|
| Locations of Controls                      | 4    |  |  |  |  |
| Basic Functions                            |      |  |  |  |  |
| Overview of Functions                      | 5    |  |  |  |  |
| Eclipse                                    |      |  |  |  |  |
| Spectral Sensitivity Characteristics       | 11   |  |  |  |  |
| Vibration Specifications                   |      |  |  |  |  |
| Key Switch Circuitry                       | 12   |  |  |  |  |
| Key Function Specifications                | 13   |  |  |  |  |
| Initial Settings, Custom Preset and Backup |      |  |  |  |  |
| Mode Condition                             | 17   |  |  |  |  |
| Command List                               | 20   |  |  |  |  |
| VISCA/RS-232C Commands                     | 20   |  |  |  |  |
| FCB Series Camera Commands                 |      |  |  |  |  |
| Specifications                             | 42   |  |  |  |  |
| Precautions                                | . 45 |  |  |  |  |


# **Features**

- 10× optical zoom.
- Adopts a newly developed DSP for improved picture quality when using the digital zoom or the slow shutter.
- VISCA is a communications protocol, which enables the camera to be controlled remotely by commands from a host computer/controller.
- Six memory locations are provided to temporarily save and recall up to six sets of camera settings.
- The EX-view HAD CCD features 380,000 effective picture elements and shooting with enhanced sensitivity. The minimum illumination required is 1.5 lux (1/60 s (NTSC), 1/50 s (PAL)).

With consideration given to environmental protection, this module is designed to operate with low power consumption and incorporates lead-free and halogenfree circuit boards.

# Locations of Controls

# **Main Unit**



- 1 Lens
- 2 CN901 connector
- 3 WIDE button
- 4 TELE button

- 5 CN701 connector
- 6 CN751 connector
- 7 Tripod screw holes

When a tripod is used, please use 5.5 mm ( $^{7}/_{32}$  in.) screws to attach it to the camera. Also, please be sure to attach the tripod securely.

# **Basic Functions**

# **Overview of Functions**

VISCA commands form the basis of camera control.

# **Timing Chart**

As VISCA Command processing can only be carried out once in a Vertical cycle, it takes the maximum 1V cycle time for an ACK/Completion to be returned. If the Command ACK/Completion communication time can be cut shorter than the 1V cycle time, then every 1V cycle can receive a Command.

# General Commands Command ACK Completion TxD Within 16.7msec (20msec\*PAL) Query Command RxD Within 16.7msec (20msec\*PAL) Command TxD Completion TxD

### General

### Power On/Off

Powers the camera on and off. When the power is off, the camera is able to accept only the lowest level of VISCA Commands; the display and other features are turned off.

### • I/F clear

Clears the Command buffer of the FCB series camera. Clearing the buffer can also be carried out from the control application software when the power is on.

### Address set

VISCA is a protocol, which normally can support a daisy chain of up to seven attached devices.

Whenever a camera is connected for the first time, be sure to use the address set to confirm the address.

# • ID Write

Sets the camera ID.

# • Mute

Blanks the screen and sends out a synchronizing signal.

### • Lens Initialization

Initializes the zoom and focus of the lens. Even when power is already on, it initializes the zoom and the focus.

# Comp Scan

A pixel blemish-masking feature is used to reevaluate overall CCD pixel blemishes and mask severely flawed pixels automatically upon receiving the COMP SCAN command. This feature helps to mask the flaws found in CCD imagers, even after the camera has been powered on for some time.

### Zoom

The FCB series camera employs an  $10\times$  optical zoom lens combined with a digital zoom function allowing you to zoom up to  $40\times$ .

**Lens specifications:** Optical  $10\times$ , f = 4.2 to 42 mm (F1.8 to F2.9)

The horizontal angle of view is approximately 46 degrees (wide end) to 4.6 degrees (tele end). Digital Zoom enlarges the center of the subject by expanding each image in both the vertical and horizontal directions. When 40× zoom is used, the number of effective picture elements in each direction reduces to <sup>1</sup>/<sub>4</sub> and the overall resolution deteriorates.

You can activate the zoom in the following two ways:

- By pressing the TELE or WIDE button on the camera itself.
- Using a VISCA Command

# Using Standard Mode Using Variable Mode

There are eight levels of zoom speed.

### **Direct Mode**

Setting the zoom position enables quick movement to the designated position.

# **Digital Zoom ON/OFF**

In these standard and variable Speed Modes, it is necessary to send a "Stop Command" to stop the zoom operation.

• The Zoom Mode supports a Combined Mode and a Separate Mode.

### **Combined Mode**

This is the previously existing zoom method. After the optical zoom has reached its maximum level, the camera switches to Digital Zoom Mode.

# Separate Mode

In this mode, Optical Zoom and Digital Zoom can be operated separately. You can use digital zoom magnification at any time from within any level of optical magnification.

# **Focus**

Focus has the following modes, all of which can be set using VISCA Commands.

### Auto Focus Mode

The minimum focus distance is 10 mm at the optical wide end and 1000 mm at the optical tele end, and is independent of the digital zoom.

The AutoFocus (AF) function automatically adjusts the focus position to maximize the high frequency content of the picture in a center measurement area, taking into consideration the high luminance and strong contrast components.

### - Normal AF Mode

This is the normal mode for AF operations.

# - Interval AF Mode

The mode used for AF movements carried out at defined intervals. The time intervals for AF movements and for the timing of the stops can be set in one-second increments using the Set Time Command. The initial value for both is set to five seconds.

# - Zoom Trigger Mode

When the zoom is changed with the TELE button, WIDE button, VISCA Zoom commands or key switches, the pre-set value (initially set at 5 seconds) becomes that for AF Mode. Then, it returns to Manual Focus mode.

AF sensitivity can be set to either HIGH or LOW.

### - HIGH

Reaches the highest focus speed quickly. Use this when shooting a subject that moves frequently. Usually, this is the most appropriate mode.

### - LOW

Improves the stability of the focus. When the lighting level is low, the AF function does not take effect, even though the brightness varies, contributing to a stable image.

When used for 24 hours continuously, initialization of lens system once a day is recommended because this will make the life of lens longer. The Initialize Lens Command takes a little less than 3 seconds to initialize the focus and zoom.

### • Manual Focus Mode

Manual Focus has both a Standard Speed Mode and a Variable Speed Mode. Standard Speed Mode focuses at a fixed rate of speed. Variable Speed Mode has eight speed levels that can be set using a VISCA Command.

# • One Push Trigger Mode

When a Trigger Command is received, the lens moves to adjust the focus for the subject. The focus lens then holds the same position until the next Trigger Command is input.

# • Infinity Mode

The lens is forcibly moved to a position suitable for an unlimited distance.

# • Near Limit Mode

Can be set in a range from  $1000 (\infty)$  to C000 (10 mm).

### White Balance

White Balance has the following modes, all of which can be set using VISCA Commands.

# • Auto White Balance

This mode computes the white balance value output using color information from the entire screen. It outputs the proper value using the color temperature radiating from a black subject based on a range of values from 3000 to 7500K.

This mode is the default setting.

### • ATW

Auto Tracing White balance (2000 to 10000 K)

### Indoor

3200 K Base Mode

### Outdoor

5800 K Base Mode

## • One Push WB

The One Push White Balance mode is a fixed white balance mode that may be automatically readjusted only at the request of the user (One Push Trigger), assuming that a white subject, in correct lighting condition, and occupying more than <sup>1</sup>/<sub>2</sub> of the image, is submitted to the camera.

One Push White Balance data is lost when the power is turned off. If the power is turned off, reset the One Push White Balance.

### • Manual WB

Manual control of R and B gain, 256 steps each

# **Automatic Exposure Mode**

The variety of AE functions, which allow video signal to output the optimum image for subjects from low light conditions to bright light conditions, are available.

### • Full Auto

Auto Iris and Gain, Fixed Shutter Speed (NTSC: 1/60 s, PAL: 1/50 s)

# • Shutter Priority 1)

Variable Shutter Speed, Auto Iris and Gain (1/1 to 1/10,000 s, 22 steps, std. shutter: 16 steps, slow shutter: 6 steps)

### • Iris Priority

Variable Iris (F1.8 to Close, 18 steps), Auto Gain and Shutter speed

# • Manual

Variable Shutter, Iris and Gain

# • Bright

Variable Iris and Gain (Close to F1.8, 17 steps at 0 dB: F1.8, 15 steps from 0 to 28 dB)

# **AE – Shutter Priority**

The shutter speed can be set freely by the user to a total of 22 steps – 16 high speeds and 6 low speeds. When the slow shutter is set, the speed can be  $^{1}/_{30}$ ,  $^{1}/_{15}$ ,  $^{1}/_{8}$ , or  $^{1}/_{4}$  s. The picture output is read at a normal rate from the memory. The memory is updated at a low rate from the CCD. AF capability is low.

In high speed mode, the shutter speed can be set up to  $^{1}/_{10,000}$  s. The iris and gain are set automatically, according to the brightness of the subject.

| Data | NTSC  | PAL   |
|------|-------|-------|
| 15   | 10000 | 10000 |
| 14   | 6000  | 6000  |
| 13   | 4000  | 3500  |
| 12   | 3000  | 2500  |
| 11   | 2000  | 1750  |
| 10   | 1500  | 1250  |
| 0F   | 1000  | 1000  |
| 0E   | 725   | 600   |
| 0D   | 500   | 425   |
| 0C   | 350   | 300   |
| 0B   | 250   | 215   |
| 0A   | 180   | 150   |
| 09   | 125   | 120   |
| 08   | 100   | 100   |
| 07   | 90    | 75    |
| 06   | 60    | 50    |
| 05   | 30    | 25    |
| 04   | 15    | 12    |
| 03   | 8     | 6     |
| 02   | 4     | 3     |
| 01*  | 2     | 2     |
| 00*  | 1     | 1     |

<sup>\*</sup> For AE-Manual only.

# AE - Iris Priority

The iris can be set freely by the user to 18 steps between F1.8 and Close.

The gain and shutter speed are set automatically according to the brightness of the subject.

| Data | Setting value | Data | Setting value |
|------|---------------|------|---------------|
| 11   | F1.8          | 08   | F8            |
| 10   | F2.0          | 07   | F9.6          |
| 0F   | F2.4          | 06   | F11           |
| 0E   | F2.8          | 05   | F14           |
| 0D   | F3.4          | 04   | F16           |
| 0C   | F4.0          | 03   | F19           |
| 0B   | F4.8          | 02   | F22           |
| 0A   | F5.6          | 01   | F28           |
| 09   | F6.8          | 00   | CLOSE         |

<sup>1)</sup> Flicker can be eliminated by setting shutter to:

<sup>→</sup> ¹/100 s for NTSC models used in countries with a 50 Hz power supply frequency.

<sup>→ 1/120</sup> s for PAL models used in countries with a 60 Hz power supply frequency.


### AE - Manual

The shutter speed (22 steps), iris (18 steps) and gain (16 steps) can be set freely by the user.

# AE - Bright

The bright control function adjusts both the gain and iris using an internal algorithm according to a brightness level freely set by the user. Exposure is controlled by gain when dark, and by iris when bright. As both gain and iris are fixed, this mode is used when exposing at a fixed camera sensitivity. When switching from Full Auto or Shutter Priority Mode to Bright Mode, the current status will be retained for a short period of time.

Only when the AE mode is set to "Full Auto" or "Shutter Priority," the user can switch it to "Bright."




| Data | Iris | Gain  | Data | Iris  | Gain |
|------|------|-------|------|-------|------|
| 1F   | F1.8 | 28 dB | 0F   | F2.4  | 0 dB |
| 1E   | F1.8 | 26 dB | 0E   | F2.8  | 0 dB |
| 1D   | F1.8 | 24 dB | 0D   | F3.4  | 0 dB |
| 1C   | F1.8 | 22 dB | 0C   | F4.0  | 0 dB |
| 1B   | F1.8 | 20 dB | 0B   | F4.8  | 0 dB |
| 1A   | F1.8 | 18 dB | 0A   | F5.6  | 0 dB |
| 19   | F1.8 | 16 dB | 09   | F6.8  | 0 dB |
| 18   | F1.8 | 14 dB | 08   | F8.0  | 0 dB |
| 17   | F1.8 | 12 dB | 07   | F9.6  | 0 dB |
| 16   | F1.8 | 10 dB | 06   | F11   | 0 dB |
| 15   | F1.8 | 8 dB  | 05   | F14   | 0 dB |
| 14   | F1.8 | 6 dB  | 04   | F16   | 0 dB |
| 13   | F1.8 | 4 dB  | 03   | F19   | 0 dB |
| 12   | F1.8 | 2 dB  | 02   | F22   | 0 dB |
| 11   | F1.8 | 0 dB  | 01   | F28   | 0 dB |
| 10   | F2.0 | 0 dB  | 00   | CLOSE | 0 dB |

When switching from the Shutter Priority mode to the Bright mode, the shutter speed set in the Shutter Priority mode is maintained.

# **Spot Exposure Mode**

In Full Auto AE, the level for the entire screen is computed and the optimum Auto Iris and Gain levels are determined. In Spot AE, a particular section of the subject can be designated, and then that portion of the image can be weighted and a value computed so that Iris and Gain can be optimized to obtain an image. For example, in an image with a lot of movement and with varying levels of brightness, portions without much change can be designated as such a "spot," and changes to the screen can be minimized in that area. As shown in the diagram below, a range of 16 blocks vertically and 16 blocks horizontally can be designated.

In the case where the center is designated (shown in black), the level is computed along with a weighted value for the surrounding block (shaded), including the specified portions; and then the Gain and Iris are set. The value of the designated portions and the surrounding areas should be calculated as 90% and the rest should be set to 10%.



# **Exposure Compensation**

Exposure compensation is a function which offsets the internal reference brightness level used in the AE mode by steps of 1.5 dB.

| Data | Step | Setting value |
|------|------|---------------|
| 0E   | 7    | 10.5 dB       |
| 0D   | 6    | 9 dB          |
| 0C   | 5    | 7.5 dB        |
| 0B   | 4    | 6 dB          |
| 0A   | 3    | 4.5 dB        |
| 09   | 2    | 3 dB          |
| 08   | 1    | 1.5 dB        |
| 07   | 0    | 0 dB          |
| 06   | -1   | -1.5 dB       |
| 05   | -2   | -3 dB         |
| 04   | -3   | -4.5 dB       |
| 03   | -4   | -6 dB         |
| 02   | -5   | -7.5 dB       |
| 01   | -6   | -9 dB         |
| 00   | -7   | -10.5 dB      |

# **Aperture Control**

Aperture control is a function which adjusts the enhancement of the edges of objects in the picture. There are 16 levels of adjustment, starting from "no enhancement." When shooting text, this control may help by making the text sharper.

# **Back Light Compensation**

When the background of the subject is too bright, or when the subject is too dark due to shooting in the AE mode, back light compensation will make the subject appear clearer.

### Slow Shutter - Auto/Manual

When the Slow Shutter is set to "Auto," this ensures that the slow shutter is engaged automatically when the brightness drops. This occurs only when the AE mode is set to "Full Auto."

"Slow Shutter Manual" is the factory setting.

### Camera ID

The ID can be set up to 65,536 (0000 to FFFF). As this will be memorized in the nonvolatile memory inside the camera, data will be saved regardless of whether it has been backed up.

### **Effect**

It consists of the following functions.
• Neg. Art: Negative/Positive Reversal

• Black White: Monochrome Image

## **Others**

# **Mirror Image**

The video output from the camera can be reversed left and right using this function.

### **Freeze**

This function captures an image in the field memory of the camera so that this image can be output continuously.

Because communication inside the camera is based on V cycle, the captured image is always the one 3V to 4Vs after the sending of a Command. Thus, you can not specify a time period after sending EVEN, ODD or a Command.

# **Memory (Position Preset)**

Using the position preset function, 6 sets of camera shooting conditions can be stored and recalled. This function allows you to achieve the desired status instantly even without adjusting the following items each time:

- Zoom Position
- Digital Zoom On/Off
- Focus Auto/Manual
- Focus Position
- AE Mode
- Shutter control parameters
- Bright Control
- Iris control parameters
- Gain control parameters
- Exposure Compensation On/Off
- Exposure Level
- Backlight Compensation On/Off
- Slow Shutter Auto/Manual
- White Balance Mode
- R/B Gain
- Aperture

# **Custom Preset**

As with the position preset function, the camera shooting conditions can be stored and recalled. The settings are recalled when the power is turned on. For setting items, refer to the "Initial Settings, Custom Preset and Backup" section on page 15.

# **Title Display**

The camera can be given a title containing up to 20 characters such as "ENTRANCE" or "LOBBY". The position of the first character (horizontal, vertical) of the title, blinking state, and color can also be changed.

| Vposition | 00 to 0A |           |  |  |
|-----------|----------|-----------|--|--|
| Hposition | 00 to 17 |           |  |  |
| Blink     | 00: Does | not blink |  |  |
| ВППК      | 01: E    | Blinks    |  |  |
|           | 00       | White     |  |  |
|           | 01       | Yellow    |  |  |
|           | 02       | Violet    |  |  |
| Color     | 03       | Red       |  |  |
|           | 04       | Cyan      |  |  |
|           | 05       | Green     |  |  |
|           | 06       | Blue      |  |  |


| 00 | 01 | 02 | 03 | 04 | 05 | 06 | 07 |
|----|----|----|----|----|----|----|----|
| A  | В  | C  | D  | E  | F  | G  | Н  |
| 08 | 09 | 0a | 0b | 0c | 0d | 0e | 0f |
| I  | J  | K  | L  | M  | N  | O  | P  |
| 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
| Q  | R  | S  | T  | U  | V  | W  | X  |
| 18 | 19 | 1a | 1b | 1c | 1d | 1e | 1f |
| Y  | Z  | &  |    | ?  | !  | 1  | 2  |
| 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |
| 3  | 4  | 5  | 6  | 7  | 8  | 9  | 0  |
| 28 | 29 | 2a | 2b | 2c | 2d | 2e | 2f |
| À  | È  | Ì  | Ò  | Ù  | Á  | É  | Í  |
| 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 |
| Ó  | Ú  | Â  | Ê  | Ô  | Æ  | Œ  | Ã  |
| 38 | 39 | 3a | 3b | 3c | 3d | 3e | 3f |
| Õ  | Ñ  | Ç  | В  | Ä  | Ϊ  | Ö  | Ü  |
| 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 |
| Å  | \$ | ₽  | ¥  | DM | £  | i  | i  |
| 48 | 49 | 4a | 4b | 4c | 4d | 4e | 4f |
| ø  | 44 | :  | 6  |    | ,  | /  | -  |

# **Date and Time Display**

The date and time (accuracy: ±30 s/month) can be displayed on the video monitor using a Display command.

# **Eclipse**

When designing the housing, refer to the dimensional allowance as shown in the figure below.




# Vibration Specifications

# **Test Method (Random vibration)**


- Fix the camera at the four fixation points of the base using M2 screws.
- Perform the random vibration test under the following conditions in the X, Y and Z directions for 20 minutes in each direction.
- The camera vibration specification is to have no malfunction after this test.

| Power spectrum density  | 5 to 50 Hz 4.14 m <sup>2</sup> /s <sup>3</sup> {0.043 G <sup>2</sup> /Hz}<br>50 to 100 Hz -36 dB/oct |
|-------------------------|------------------------------------------------------------------------------------------------------|
| Effective overall value | 14.3 m/s <sup>2</sup> {1.46 G}                                                                       |
| Test time               | 20 minutes                                                                                           |

# Spectral Sensitivity Characteristics



# **Key Switch Circuitry**



# **Key Function Specifications**

| Classification | Name           | Function                                                                                                                              | Button operation                                                                                            | Mode display                                                                                                                           |
|----------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| ZOOM           | WIDE           | Move ZOOM to WIDE side quickly.                                                                                                       | Pressing repeatedly allowed.                                                                                | ZOOM bar displayed for 3 s.                                                                                                            |
|                | WIDE SLOW      | Move ZOOM to WIDE side slowly.                                                                                                        | Pressing repeatedly allowed.                                                                                | ZOOM bar displayed for 3 s.                                                                                                            |
|                | TELE SLOW      | Move ZOOM to TELE side slowly.                                                                                                        | Pressing repeatedly allowed.                                                                                | ZOOM bar displayed for 3 s.                                                                                                            |
|                | TELE FAST      | Move ZOOM to TELE side quickly.                                                                                                       | Pressing repeatedly allowed.                                                                                | ZOOM bar displayed for 3 s.                                                                                                            |
| D-ZOOM         | DZOOM          | Turn on/off the mode for shifting from optical MAX to electronic ZOOM in combined mode.                                               | Switch on/off.                                                                                              | ZOOM bar displayed for 3 s.                                                                                                            |
|                | DZOOM<br>WIDE  | Move the electronic ZOOM to WIDE side in separate mode.                                                                               | Pressing repeatedly allowed.                                                                                | ZOOM bar displayed for 3 s.                                                                                                            |
|                | DZOOM<br>TELE  | Move the electronic ZOOM to TELE side in separate mode.                                                                               | Pressing repeatedly allowed.                                                                                | ZOOM bar displayed for 3 s.                                                                                                            |
|                | DZOOM<br>MAX   | Switch the electronic ZOOM between 1× and MAX in separate mode.                                                                       | Switch between 1× and MAX magnification.                                                                    | ZOOM bar displayed for 3 s.                                                                                                            |
| FOCUS          | AF             | Switch between Auto Focus and Manual Focus.                                                                                           | Switch between Auto and Manual.                                                                             | Manual F indication                                                                                                                    |
|                | NEAR           | Move focus to NEAR side in Manual Focus mode.                                                                                         | Pressing repeatedly allowed.                                                                                | Near indication                                                                                                                        |
|                | FAR            | Move focus to FAR side in Manual Focus mode.                                                                                          | Pressing repeatedly allowed.                                                                                | Far indication                                                                                                                         |
|                | ONE PUSH<br>AF | Perform AF operation once in Manual Focus mode.                                                                                       | Request One Push AF.                                                                                        | Manual F indication flashes while request is made.                                                                                     |
|                | INFINITY       | Move focus forcibly to Infinity resulting in Manual Focus mode, regardless of the current focus mode.                                 | Request Infinity.                                                                                           | Far indication                                                                                                                         |
| AE             | AE AUTO        | Switch to AE FULL Auto mode.                                                                                                          | Request AE Full Auto.                                                                                       | No display                                                                                                                             |
|                | BRIGHT         | Switch to variable brightness mode (BRIGHT), depending on the conditions for mode shifting.                                           | Request Bright mode. Pressing Up/Down key repeatedly allowed.                                               | Bright bar display                                                                                                                     |
|                | SHUTTER        | Shutter priority AE mode                                                                                                              | Request shutter priority AE mode.                                                                           | Shutter code display                                                                                                                   |
|                | IRIS           | Iris priority AE mode                                                                                                                 | Request iris priority AE mode.                                                                              | Iris code display                                                                                                                      |
|                | BACK<br>LIGHT  | Switch backlight on/off.                                                                                                              | Switch on/off.                                                                                              | Backlight indication                                                                                                                   |
| WB             | AUTO WB        | Switch to AUTO WB mode.                                                                                                               | Request Auto WB mode.                                                                                       | No display                                                                                                                             |
|                | ONE PUSH<br>WB | Switch to One Push WB mode when pressed once and capture data when pressed 2nd time.                                                  | Request One Push WB mode and trigger.                                                                       | One Push indication<br>flashes at 0.8 Hz<br>before capturing data,<br>at 3.2 Hz during<br>capturing, and stays<br>lit after capturing. |
|                | ATW            | Switch to ATW mode.                                                                                                                   | Request AWB mode.                                                                                           | ATW display                                                                                                                            |
|                | INDOOR         | Enable WB at 3200K in INDOOR mode.                                                                                                    | Request Indoor mode.                                                                                        | Indoor indication                                                                                                                      |
|                | OUTDOOR        | Enable WB at 5800K in OUTDOOR mode.                                                                                                   | Request Outdoor mode.                                                                                       | Outdoor indication                                                                                                                     |
|                | MANUAL<br>WB   | Switch to Manual WB mode. Enable R control when pressed once and enable B control when pressed 2nd time. Switchable with UP/DOWN key. | Switch between R control<br>and B control in manual WB<br>mode./Pressing Up/Down<br>key repeatedly allowed. | "WB-MAN"<br>(character display)                                                                                                        |

| Classification | Name                 | Function                                                                                                                                                                | Button operation                                                                           | Mode display                                    |
|----------------|----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|-------------------------------------------------|
| FEATURE        | FREEZE               | Capture still image.                                                                                                                                                    | Switch on/off.                                                                             | FREEZE indication                               |
|                | LR-<br>REVERSE       | Horizontal reversal                                                                                                                                                     | Switch on/off.                                                                             | Horizontal reversal indication                  |
|                | BLACK &<br>WHITE     | Black-and-white output                                                                                                                                                  | Switch on/off.                                                                             | B&W display                                     |
|                | NEGA ART             | Negative art output                                                                                                                                                     | Switch on/off.                                                                             | Neg Art display                                 |
|                | MUTE                 | Mute video output                                                                                                                                                       | Switch on/off.                                                                             | "MUTE" (character display)                      |
| DISPLAY        | TIME/DATE<br>SET     | Set date and time. Start setting with Exec, make settings with Up/ Down key, and confirm settings with Exec.                                                            | Request setting. → Setting is started with Exec.  Pressing Up/Down key repeatedly allowed. | Setting screen display                          |
|                | TIME/DATE<br>DISPLAY | Switch display mode between OFF $\rightarrow$ time display $\rightarrow$ date display $\rightarrow$ date and time display mode and time display $\rightarrow$ OFF mode. | Switch date display/time display/off selection.                                            | Date/time display                               |
|                | DISPLAY              | Display                                                                                                                                                                 | Switch on/off.                                                                             |                                                 |
|                | TITLE                | Title setting                                                                                                                                                           | Request setting. → Setting is started with Exec.  Pressing Up/Down key repeatedly allowed. | Title setting screen display                    |
|                | EXEC                 | Confirm title/clock settings.                                                                                                                                           | Select with Up/Down and confirm with Exec.                                                 | Setting screen selection highlighted in yellow. |
| UP/DOWN        | UP                   | Data UP key (priority for AE mode, Bright, manual WB, title, and clock)                                                                                                 | Request UP.                                                                                | Selection highlighted.                          |
|                | DOWN                 | Data DOWN key (priority for AE mode, Bright, manual WB, title, and clock)                                                                                               | Request DOWN.                                                                              | Selection highlighted.                          |
| PRESET         | POS1                 | Recall preset position 1.                                                                                                                                               | Request recall.                                                                            | RECALL POS0                                     |
|                | POS2                 | Recall preset position 2.                                                                                                                                               | Request recall.                                                                            | RECALL POS1                                     |
|                | POS3                 | Recall preset position 3.                                                                                                                                               | Request recall.                                                                            | RECALL POS2                                     |
|                | POS4                 | Recall preset position 4.                                                                                                                                               | Request recall.                                                                            | RECALL POS3                                     |
|                | POS5                 | Recall preset position 5.                                                                                                                                               | Request recall.                                                                            | RECALL POS4                                     |
|                | POS6                 | Recall preset position 6.                                                                                                                                               | Request recall.                                                                            | RECALL POS5                                     |
|                | POS7                 | Recall custom preset.                                                                                                                                                   | Request recall.                                                                            | RECALL                                          |
|                | POS PRESET           | Write data. Enabled when pressed together with POS button.                                                                                                              | Request setting. Enabled when pressed together with POS key.                               | PRESET display                                  |
|                | POS RESET            | Delete data. Enabled when pressed together with POS button.                                                                                                             | Request deletion. Enabled when pressed together with POS key.                              | RESET display                                   |
| Others         | APERTURE<br>UP       | Increase aperture (Aperture UP)                                                                                                                                         | Request UP.                                                                                | Aperture bar displayed for 3 s.                 |
|                | AUTO SLOW<br>SHUTTER | Switch Auto Slow Shutter on/off.                                                                                                                                        | Switch on/off.                                                                             | "ASS" (character display)                       |
|                | APERTURE<br>DOWN     | Decrease aperture (Aperture DOWN)                                                                                                                                       | Request DOWN.                                                                              | Aperture bar displayed for 3 s.                 |
|                | AF<br>SENSITIVITY    | Switch AF sensitivity between Normal and Low.                                                                                                                           | Switch between Normal and Low.                                                             | "SENS L" (character display)                    |
|                | BRIGHT UP            | Raise brightness setting (Bright UP) (When not in Bright mode, switching to Bright mode is made automatically depending on the conditions.)                             | Request UP./Pressing repeatedly allowed.                                                   | Bright bar display                              |
|                | BRIGHT<br>DOWN       | Lower brightness setting (Bright DOWN) (When not in Bright mode, switching to Bright mode is made automatically depending on the conditions.)                           | Request DOWN./Pressing repeatedly allowed.                                                 | Bright bar display                              |

# Initial Settings, Custom Preset and Backup

Initial settings for the various functions of the FCB-IX11A/IX11AP are indicated in the "Initial settings" column.

The "Custom preset" column indicates whether the custom preset function can be used to store the settings. The function enables the stored settings to be recalled automatically when the camera is turned on. The "Standby backup" column indicates whether the data is preserved even when the camera is powered OFF. A circle "O" in this column signifies that the data is preserved. A cross "x" signifies that the data IS NOT preserved.

| Mode/Position                | Initial settings                  | Custom | Standby<br>backup |
|------------------------------|-----------------------------------|--------|-------------------|
| Zoom Position                | Wide end                          | 0      | 0                 |
| D-Zoom On/Off                | On                                | 0      | 0                 |
| D-Zoom Separate/Combine      | Combine                           | 0      | 0                 |
| D-Zoom Position              | 00h                               | 0      | 0                 |
| Focus Position               | _                                 | 0      | 0                 |
| Focus Auto/Manual            | Auto                              | 0      | 0                 |
| Near Limit Setting           | 8000h (40cm)                      | 0      | 0                 |
| AF Sensitivity               | Normal                            | 0      | 0                 |
| AF Mode                      | Normal                            | 0      | 0                 |
| AF Run Time                  | 5 sec                             | 0      | 0                 |
| AF Interval                  | 5 sec                             | 0      | 0                 |
| WB Mode                      | Auto                              | 0      | 0                 |
| WB Data (Rgain, Bgain)       | _                                 | 0      | 0                 |
| One Push WB Data             | _                                 | 0      | 0                 |
| AE Mode                      | Full Auto                         | 0      | 0                 |
| Slow Shutter Mode            | Manual                            | 0      | 0                 |
| Shutter Position             | 1/60sec (NTSC), 1/50sec (PAL)     | 0      | 0                 |
| Iris Position                | _                                 | 0      | 0                 |
| Gain Position                | _                                 | 0      | 0                 |
| Bright Position              | _                                 | 0      | 0                 |
| Exposure Compensation On/Off | Off                               | 0      | 0                 |
| Exposure Compensation Amount | ±0                                | 0      | 0                 |
| Backlight On/Off             | Off                               | 0      | 0                 |
| Spot AE On/Off               | Off                               | 0      | 0                 |
| Spot AE Position Setting     | X=8, Y=8                          | 0      | 0                 |
| Aperture Level               | 5                                 | 0      | 0                 |
| LR Reverse On/Off            | Off                               | 0      | 0                 |
| Freeze On/Off                | Off                               | ×      | ×                 |
| Picture Effect               | Off                               | 0      | 0                 |
| Camera Memory                | Same as the initial value setting | 0      | 0                 |
| Display On/Off               | Off                               | 0      | 0                 |
| Mute On/Off                  | Off                               | ×      | ×                 |

| Mode/Position        | Initial settings | Custom preset | Standby<br>backup |
|----------------------|------------------|---------------|-------------------|
| Title Display On/Off | Off              | 0             | 0                 |
| Title Setting        | _                | 0             | 0                 |
| Key Lock On/Off      | Off              | 0             | 0                 |
| Camera ID            | 0000h            | 0             | 0                 |

# Note

The number of times data can be written to EEPROM (by executing Custom Preset) is limited.

# **Mode Condition**

# ondition

| Mode           | Power Off | Initializing | Power On | Freeze On | MemRecall |
|----------------|-----------|--------------|----------|-----------|-----------|
| Address Set    | 0         | 0            | 0        | 0         | 0         |
| IF_Clear       | 0         | 0            | 0        | 0         | 0         |
| Command Cancel | 0         | 0            | 0        | 0         | 0         |
| Power On/Off   | 0         | 0            | 0        | 0         | 0         |

# Lens

| Mode                                | Power Off | Initializing | Power On | Freeze On | MemRecall | Zoom Direct | Focus Direct | ZmFo Direct | Focus Auto |
|-------------------------------------|-----------|--------------|----------|-----------|-----------|-------------|--------------|-------------|------------|
| Zoom Tele/Wide/Stop                 | ×         | ×            | 0        | ×         | ×         | ×           | 0            | ×           | 0          |
| Zoom Direct                         | ×         | ×            | 0        | ×         | ×         | 0           | 0            | ×           | 0          |
| Zoom Focus Direct                   | ×         | ×            | 0        | ×         | ×         | ×           | ×            | 0           | ×          |
| D-Zoom On/Off                       | ×         | ×            | 0        | ×         | ×         | ×           | 0            | ×           | 0          |
| D-Zoom Separate/Combine             | ×         | ×            | 0        | ×         | ×         | ×           | 0            | ×           | 0          |
| D-Zoom Tele/Wide/Stop               | ×         | ×            | 0        | ×         | ×         | 0           | 0            | 0           | 0          |
| D-Zoom ×1/Max                       | ×         | ×            | 0        | ×         | ×         | 0           | 0            | 0           | 0          |
| D-Zoom Direct                       | ×         | ×            | 0        | ×         | ×         | 0           | 0            | 0           | 0          |
| Focus Far/Near/Stop                 | ×         | ×            | 0        | ×         | ×         | 0           | ×            | ×           | ×          |
| Focus Direct                        | ×         | ×            | 0        | ×         | ×         | 0           | 0            | ×           | ×          |
| Focus Auto/Manual                   | ×         | ×            | 0        | ×         | ×         | 0           | ×            | ×           | 0          |
| One Push AF                         | ×         | ×            | 0        | ×         | ×         | 0           | ×            | ×           | ×          |
| Focus Infinity                      | ×         | ×            | 0        | ×         | ×         | 0           | ×            | ×           | 0          |
| Focus Near Limit                    | ×         | ×            | 0        | ×         | ×         | 0           | ×            | ×           | 0          |
| AF Sensitivity Normal/Low           | ×         | ×            | 0        | ×         | ×         | 0           | 0            | 0           | 0          |
| AF Mode Norm/Interval/Zoom          | ×         | ×            | 0        | ×         | ×         | 0           | 0            | 0           | 0          |
| AF Activation Time/Interval Setting | ×         | ×            | 0        | ×         | ×         | 0           | 0            | 0           | 0          |
| Camera Memory Set/Reset             | ×         | ×            | 0        | 0         | ×         | ×           | ×            | ×           | 0          |
| Camera Memory Recall                | ×         | ×            | 0        | 0         | *         | ×           | ×            | ×           | 0          |
| Lens Initialization                 | ×         | ×            | 0        | 0         | ×         | ×           | ×            | ×           | 0          |
| Comp Scan                           | ×         | ×            | 0        | 0         | ×         | ×           | ×            | ×           | 0          |
| 11.                                 |           |              |          |           |           |             |              |             |            |

 $<sup>* \</sup>times during recalling from key$ 

# White Balance

| Mode               | Power Off | Power Off Initializing | Power On | Freeze On | MemRecall | WB AUTO | Indoor | Outdoor | OnePush | ATW | Manual |
|--------------------|-----------|------------------------|----------|-----------|-----------|---------|--------|---------|---------|-----|--------|
| WB Mode Switchover | ×         | ×                      | 0        | ×         | ×         | 0       | 0      | 0       | 0       | 0   | 0      |
| One Push WB        | ×         | ×                      | 0        | ×         | ×         | ×       | ×      | ×       | 0       | ×   | ×      |
| RGain Setting      | ×         | ×                      | 0        | ×         | ×         | ×       | ×      | ×       | ×       | ×   | 0      |
| BGain Setting      | ×         | ×                      | 0        | ×         | ×         | ×       | ×      | ×       | ×       | ×   | 0      |

# Exposure

| Mode                          | Power Off | Initializing | Power On | Freeze On | MemRecall | AE Full Auto | AE Manual | ShutterPriority | Iris Priority | Bright |
|-------------------------------|-----------|--------------|----------|-----------|-----------|--------------|-----------|-----------------|---------------|--------|
| AE Full Auto                  | ×         | ×            | 0        | ×         | ×         | 0            | 0         | 0               | 0             | 0      |
| AE Manual                     | ×         | ×            | 0        | ×         | ×         | 0            | 0         | 0               | 0             | 0      |
| Shutter Priority              | ×         | ×            | 0        | ×         | ×         | 0            | 0         | 0               | 0             | 0      |
| Iris Priority                 | ×         | ×            | 0        | ×         | ×         | 0            | 0         | 0               | 0             | 0      |
| Bright                        | ×         | ×            | 0        | ×         | ×         | 0            | ×         | 0               | ×             | 0      |
| Shutter Setting               | ×         | ×            | 0        | ×         | ×         | ×            | 0         | 0               | ×             | ×      |
| Iris Setting                  | ×         | ×            | 0        | ×         | ×         | ×            | 0         | ×               | 0             | ×      |
| Gain Setting                  | ×         | ×            | 0        | ×         | ×         | ×            | 0         | ×               | ×             | ×      |
| Bright Setting                | ×         | ×            | 0        | ×         | ×         | ×            | ×         | ×               | ×             | 0      |
| Slow Shutter Auto/Manual      | ×         | ×            | 0        | ×         | ×         | 0            | 0         | 0               | 0             | 0      |
| Exposure Compensation On/Off  | ×         | ×            | 0        | ×         | ×         | 0            | 0         | 0               | 0             | 0      |
| Exposure Compensation Setting | ×         | ×            | 0        | ×         | ×         | 0            | 0         | 0               | 0             | 0      |
| Backlight On/Off              | ×         | ×            | 0        | ×         | ×         | 0            | ×         | ×               | ×             | ×      |
| SpotAE On/Off                 | ×         | ×            | 0        | ×         | ×         | 0            | 0         | 0               | 0             | 0      |
| SpotAE Setting                | ×         | ×            | 0        | ×         | ×         | 0            | 0         | 0               | 0             | 0      |
|                               |           |              |          |           |           |              |           |                 |               |        |

# Others

| Моде                   | Power Off | Initializing | Power On | Freeze On | MemRecall |
|------------------------|-----------|--------------|----------|-----------|-----------|
| Aperture Setting       | ×         | ×            | 0        | ×         | ×         |
| LR_Reverse On/Off      | ×         | ×            | 0        | ×         | ×         |
| Freeze On/Off          | ×         | ×            | 0        | 0         | ×         |
| Sicture Effect Setting | ×         | ×            | 0        | ×         | ×         |
| Display On/Off         | ×         | ×            | 0        | 0         | 0         |
| Mute On/Off            | ×         | ×            | 0        | 0         | 0         |
| Fitle Setting          | ×         | ×            | 0        | 0         | 0         |
| Key Lock On/Off        | ×         | ×            | 0        | 0         | 0         |
| D Write                | ×         | ×            | 0        | 0         | 0         |
|                        |           |              |          |           |           |

# **Command List**

# VISCA<sup>1</sup>/RS-232C Commands

This Manual outlines an RS-232C control protocol and command list for certain Sony cameras from which control software can be developed.

THIS CONTROL PROTOCOL AND COMMAND LIST IS PROVIDED BY SONY ON AN "AS-IS BASIS" WITHOUT WARRANTY OF ANY KIND. SONY DOES NOT WARRANT ANY PARTICULAR RESULT FROM THE USE OF THIS CONTROL PROTOCOL AND COMMAND LIST AND DISCLAIMS AND EXCLUDES ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THAT CONTROL PROTOCOL AND COMMAND LIST, INCLUDING, BUT NOT LIMITED TO, ANY OR ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN FACT, SONY SPECIFICALLY ACKNOWLEDGES THAT SOFTWARE DEVELOPED BASED ON THIS CONTROL PROTOCOL AND COMMAND LIST MAY CAUSE MALFUNCTION OR DAMAGE TO HARDWARE AND SOFTWARE USED WITH IT (INCLUDING SONY HARDWARE AND SOFTWARE) AND SPECIFICALLY DISCLAIMS ANY LIABILITY FOR ANY SUCH MALFUNCTION OR DAMAGE. THIS CONTROL PROTOCOL AND COMMAND LIST SHOULD BE USED WITH CAUTION.


# **Overview of VISCA**

In VISCA the device outputting commands, for example, a computer, is called the controller. The device receiving the commands, an FCB series camera is called the peripheral device. In this case, an FCB series camera, is itself one of the peripheral devices. In VISCA, up to seven peripheral devices like the FCB series camera can be connected to one controller using communication conforming to the RS-232C standard. The parameters of RS-232C are as follows:

Communication speed: 9.6 kbps/19.2 kbps/ 38.4 kbps

Data bits: 8Start bit: 1Stop bit: 1/2Non parity

Peripheral devices are connected in a daisy chain. As shown in the following figure, the actual internal connection is a one-direction ring, so that messages return to the controller via the peripheral devices. The devices on the network are assigned addresses. The address of the controller is fixed at 0. The addresses of the peripheral devices are 1, 2, 3 ... in order, starting from the one nearest the controller. The address of the peripheral device is set by sending address commands during the initialization of the network.



### VISCA network structure

### Notes

- Connect the serial output from the PC to the serial input of camera 1, then connect the serial output of camera 1 to the serial input of camera 2, the serial output of camera 2 to the serial input of camera 3, and the serial output of camera 3 to the serial input of the PC. (Up to seven cameras may be connected.)
- Power on all the units connected in series.
- Mixed existence of RS-232C and TTL signal levels is not allowed.

# **VISCA Communication Specifications**


# **VISCA Packet Structure**

The basic unit of VISCA communication is called a packet. The first byte of the packet is called the header and comprises the sender's and receiver's addresses. For example, the header of the packet sent to the FCB series camera assigned address 1 from the controller (address 0) is hexadecimal 81H. The packet sent to the FCB series camera assigned address 2 is 82H. In the command list, as the header is 8X, input the address of the FCB series camera at X. The header of the reply

packet from the FCB series camera assigned address 1 is 90H. The packet from the FCB series camera assigned address 2 is A0H.

Some of the commands for setting FCB series cameras can be sent to all devices at one time (broadcast). In the case of broadcast, the header should be hexadecimal 88H.

When the terminator is FFH, it signifies the end of the packet.



# **Command and Inquiry**

### Command

Sends operational commands to the FCB series camera.

### Inquiry

Used for inquiring about the current state of the FCB series camera.

|         | <b>Command Packet</b> | Note                             |
|---------|-----------------------|----------------------------------|
| Inquiry | 8X QQ RR FF           | QQ1) = Command/Inquiry,          |
|         |                       | RR <sup>2)</sup> = category code |

<sup>1)</sup> QQ = 01 (Command), 09 (Inquiry)

X = 1 to 7: FCB series camera address

# **Responses for Commands and Inquiries**

# ACK message

Returned by the FCB series camera when it receives a command. No ACK message is returned for inquiries.

# Completion message

Returned by the FCB series camera when execution of commands or inquiries is completed. In the case of inquiry commands, it will contain reply data for the inquiry after the 3rd byte of the packet. If the ACK message is omitted, the socket number will contain 0.

|                            | Reply Packet     | Note              |
|----------------------------|------------------|-------------------|
| Ack                        | X0 4Y FF         | Y = socket number |
| Completion (commands)      | X0 5Y FF         | Y = socket number |
| Completion (Inquiries)     | X0 5Y FF         | Y = socket number |
| Y = 0 to F: FCB series can | mara addrace ± 8 |                   |

## Error message

When a command or inquiry command could not be executed or failed, an error message is returned instead of the completion message.

| Error Packet | Description                      |
|--------------|----------------------------------|
| X0 6Y 01 FF  | Message length error (>14 bytes) |
| X0 6Y 02 FF  | Syntax Error                     |
| X0 6Y 03 FF  | Command buffer full              |
| X0 6Y 04 FF  | Command cancelled                |
| X0 6Y 05 FF  | No socket (to be cancelled)      |
| X0 6Y 41 FF  | Command not executable           |
| V 0: E E0D   |                                  |

X = 9 to F: FCB series camera address + 8, Y = socket number

### **Socket Number**

When command messages are sent to the FCB series camera, it is normal to send the next command message after waiting for the completion message or error message to return. However to deal with advanced uses, the FCB series camera has two buffers (memories) for commands, so that up to two commands including the commands currently being executed can be received. When the FCB series camera receives commands, it notifies the sender which command buffer was used using the socket number of the ACK message. As the completion message or error message also has a socket number, it indicates which command has ended. Even when two command buffers are being used at any one time, a FCB series camera management command and some inquiry messages can be executed.

The ACK message is not returned for these commands and inquiries, and only the completion message of socket number 0 is returned.

# **Command Execution Cancel**

To cancel a command which has already been sent, send the IF\_Clear command as the next command. To cancel one of any two commands which have been sent, use the cancel message.

|                 | Cancel Packet      | Note                      |
|-----------------|--------------------|---------------------------|
| Cancel          | 8X 2Y FF           | Y = socket number         |
| X = 1  to  7: F | CB series camera a | ddress, Y = socket number |

An error message will be returned for this command, but this is not a mistake. This message indicates that the command has been canceled.

<sup>&</sup>lt;sup>2)</sup> RR = 00 (Interface), 04 (camera 1), 06 (Pan/Tilter), 07 (camera 2)

KK = Maximum socket # (02)

# VISCA Device Setting Command

Before starting control of the FCB series camera, be sure to send the Address command and the IF\_Clear command using the broadcast function.

# For VISCA Network Administration

### Address

Sets an address of a peripheral device. Use when initializing the network and when receiving the network change message indicated below.

# Network Change

Sent from the peripheral device to the controller when a device is removed from or added to the network. The address must be re-set when this message is received.

Packet Note

Address 88 30 01 FF Always broadcasted.

Network Change X0 38 FF

X = 9 to F: FCB series camera address + 8

# **VISCA Interface Command**

# • IF\_Clear

Clears the command buffers in the FCB series camera and cancels the command currently being executed.

# Command Packet Reply Packet Note

IF\_Clear 8X 01 00 01FF X0 50 FF
IF\_Clear (broadcast) 88 01 00 01 FF 88 01 00 01 FF
X = 1 to 7: FCB series camera address (For inquiry packet)
X = 9 to F: FCB series camera address +8 (For reply packet)

# **VISCA Interface and Inquiry**

# ● IF\_DeviceTypeInq

Returns information on the VISCA interface.

 Inquiry
 Inquiry Packet
 Reply Packet
 Description

 IF\_DeviceTypeInq
 8X 09 00 02 FF
 Y0 50 GG GG HH
 GGGG = Vender ID

 HH JJ JJ KK FF
 (0020: Sony)
 HHHH = Model ID

 042E=FCB-IX11A
 042F=FCB-IX11AP

 JJJ = ROM revision

X = 1 to 7: FCB series camera address (For inquiry packet)
 X = 9 to F: FCB series camera address +8 (For reply packet)

# **VISCA Command/ACK Protocol**

| Command              | Command Message                | Reply Message                                                | Comments                                                                                                                   |
|----------------------|--------------------------------|--------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| General Command      | 81 01 04 38 02 FF<br>(Example) | 90 41 FF (ACK)+90 51 FF<br>(Completion)<br>90 42 FF 90 52 FF | Returns ACK when a command has been accepted, and Completion when a command has been executed.                             |
|                      | 81 01 04 38 FF<br>(Example)    | 90 60 02 FF (Syntax Error)                                   | Accepted a command which is not supported or a command lacking parameters.                                                 |
|                      | 81 01 04 38 02 FF<br>(Example) | 90 60 03 FF<br>(Command Buffer Full)                         | There are two commands currently being executed, and the command could not be accepted.                                    |
|                      | 81 01 04 08 02 FF<br>(Example) | 90 61 41 FF<br>(Command Not Executable)<br>90 62 41FF        | Could not execute the command in the current mode.                                                                         |
| Inquiry Command      | 81 09 04 38 FF<br>(Example)    | 90 50 <u>02</u> FF (Completion)                              | ACK is not returned for the inquiry command.                                                                               |
|                      | 81 09 05 38 FF<br>(Example)    | 90 60 02 FF (Syntax Error)                                   | Accepted an incompatible command.                                                                                          |
| Address Set          | 88 30 <u>01</u> FF             | 88 30 <u>02</u> FF                                           | Returned the device address to +1.                                                                                         |
| IF_Clear (Broadcast) | 88 01 00 01 FF                 | 88 01 00 01 FF                                               | Returned the same command.                                                                                                 |
| IF_Clear (For x)     | 8x 01 00 01 FF                 | z0 50 FF (Completion)                                        | ACK is not returned for this command.                                                                                      |
| Command Cancel       | 8x 2y FF                       | z0 6y 04 FF<br>(Command Canceled)                            | Returned when the command of the socket specified is canceled.  Completion for the command canceled is not returned.       |
|                      |                                | z0 6y 05 FF (No Socket)                                      | Returned when the command of the specified socket has already been completed or when the socket number specified is wrong. |

# **VISCA Camera-Issued Messages**

# **ACK/Completion Messages**

|            | Command Messages | Comments                                     |
|------------|------------------|----------------------------------------------|
| ACK        | z0 4y FF         | Returned when the command is accepted.       |
|            | (y:Socket No.)   |                                              |
| Completion | z0 5y FF         | Returned when the command has been executed. |
|            | (y:Socket No.)   |                                              |

z = Device address + 8

# **Error Messages**

|                        | Command Messages              | Comments                                                                                                                                                         |
|------------------------|-------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Syntax Error           | z0 60 02 FF                   | Returned when the command format is different or when a command with illegal command parameters is accepted.                                                     |
| Command Buffer Full    | z0 60 03 FF                   | Indicates that two sockets are already being used (executing two commands) and the command could not be accepted when received.                                  |
| Command Canceled       | z0 6y 04 FF<br>(y:Socket No.) | Returned when a command which is being executed in a socket specified by the cancel command is canceled. The completion message for the command is not returned. |
| No Socket              | z0 6y 05 FF<br>(y:Socket No.) | Returned when no command is executed in a socket specified by the cancel command, or when an invalid socket number is specified.                                 |
| Command Not Executable | z0 6y 41 FF<br>(y:Socket No.) | Returned when a command cannot be executed due to current conditions. For example, when commands controlling the focus manually are received during auto focus.  |

# **Network Change Message**

|                | Command Message | Comments                           |
|----------------|-----------------|------------------------------------|
| Network Change | z0 38 FF        | Issued when power is being routed. |

# **FCB Series Camera Commands**

# FCB Series Camera Command List (1/3)

| Command Set    | Command              | Command Packet             | Comments                           |
|----------------|----------------------|----------------------------|------------------------------------|
| AddressSet     | Broadcast            | 88 30 01 FF                |                                    |
| IF_Clear       | Broadcast            | 88 01 00 01 FF             |                                    |
| CommandCancel  |                      | 8x 2p FF                   | p: Socket No.(=1or2)               |
| CAM_Power      | On                   | 8x 01 04 00 02 FF          | Power ON/OFF                       |
|                | Off                  | 8x 01 04 00 03 FF          |                                    |
| CAM_Zoom       | Stop                 | 8x 01 04 07 00 FF          |                                    |
|                | Tele(Standard)       | 8x 01 04 07 02 FF          |                                    |
|                | Wide(Standard)       | 8x 01 04 07 03 FF          |                                    |
|                | Tele(Variable)       | 8x 01 04 07 2p FF          | p=0 (Low) to 7 (High)              |
|                | Wide(Variable)       | 8x 01 04 07 3p FF          |                                    |
|                | Direct               | 8x 01 04 47 0p 0q 0r 0s FF | pqrs: Zoom Position                |
| CAM_DZoom      | On                   | 8x 01 04 06 02 FF          | Digital zoom ON/OFF                |
|                | Off                  | 8x 01 04 06 03 FF          |                                    |
|                | Combine Mode         | 8x 01 04 36 00 FF          | Optical/Digital Zoom Combined      |
|                | Separate Mode        | 8x 01 04 36 01 FF          | Optical/Digital Zoom Separate      |
|                | Stop                 | 8x 01 04 06 00 FF          |                                    |
|                | Tele(Variable)       | 8x 01 04 06 2p FF          | p=0 (Low) to 7 (High)              |
|                | Wide(Variable)       | 8x 01 04 06 3p FF          |                                    |
|                | x1/Max               | 8x 01 04 06 10 FF          | x1/MAX Magnification Switchover    |
|                | Direct               | 8x 01 04 46 00 00 0p 0q FF | pq: D-Zoom Position                |
| CAM_Focus      | Stop                 | 8x 01 04 08 00 FF          |                                    |
|                | Far(Standard)        | 8x 01 04 08 02 FF          |                                    |
|                | Near(Standard)       | 8x 01 04 08 03 FF          |                                    |
|                | Far(Variable)        | 8x 01 04 08 2p FF          | p=0 (Low) to 7 (High)              |
|                | Near(Variable)       | 8x 01 04 08 3p FF          |                                    |
|                | Direct               | 8x 01 04 48 0p 0q 0r 0s FF | pqrs: Focus Position               |
|                | Auto Focus           | 8x 01 04 38 02 FF          | AF ON/OFF                          |
|                | Manual Focus         | 8x 01 04 38 03 FF          |                                    |
|                | Auto/Manual          | 8x 01 04 38 10 FF          |                                    |
|                | One Push Trigger     | 8x 01 04 18 01 FF          | One Push AF Trigger                |
|                | Infinity             | 8x 01 04 18 02 FF          | Forced infinity                    |
|                | Near Limit           | 8x 01 04 28 0p 0q 0r 0s FF | pqrs: Focus Near Limit Position    |
| AF Sensitivity | Normal               | 8x 01 04 58 02 FF          | AF Sensitivity High/Low            |
|                | Low                  | 8x 01 04 58 03 FF          |                                    |
| CAM_AFMode     | Normal AF            | 8x 01 04 57 00 FF          | AF Movement Mode                   |
|                | Interval AF          | 8x 01 04 57 01 FF          |                                    |
|                | Zoom Trigger AF      | 8x 01 04 57 02 FF          |                                    |
|                | Active/Interval Time | 8x 01 04 27 0p 0q 0r 0s FF | pq: Movement Time, rs: Interval    |
| CAM_ZoomFocus  | Direct               | 8x 01 04 47 0p 0q 0r 0s    | pqrs: Zoom Position                |
|                |                      | Ot Ou Ov Ow FF             | tuvw: Focus Position               |
| CAM_Initialize | Lens                 | 8x 01 04 19 01 FF          | Lens Initialization Start          |
|                | Comp Scan            | 8x 01 04 19 02 FF          | Start of Fault Correction Movement |

# FCB Series Camera Command List (2/3)

| Command Set     | Command          | Command Packet             | Comments                                 |
|-----------------|------------------|----------------------------|------------------------------------------|
| CAM_WB          | Auto             | 8x 01 04 35 00 FF          | Normal Auto                              |
|                 | Indoor           | 8x 01 04 35 01 FF          | Indoor mode                              |
|                 | Outdoor          | 8x 01 04 35 02 FF          | Outdoor mode                             |
|                 | One Push WB      | 8x 01 04 35 03 FF          | One Push WB mode                         |
|                 | ATW              | 8x 01 04 35 04 FF          | Auto Tracing White Balance               |
|                 | Manual           | 8x 01 04 35 05 FF          | Manual Control mode                      |
|                 | One Push Trigger | 8x 01 04 10 05 FF          | One Push WB Trigger                      |
| CAM_RGain       | Reset            | 8x 01 04 03 00 FF          | Manual Control of R Gain                 |
|                 | Up               | 8x 01 04 03 02 FF          |                                          |
|                 | Down             | 8x 01 04 03 03 FF          |                                          |
|                 | Direct           | 8x 01 04 43 00 00 0p 0q FF | pq: R Gain                               |
| CAM_BGain       | Reset            | 8x 01 04 04 00 FF          | Manual Control of B Gain                 |
|                 | Up               | 8x 01 04 04 02 FF          |                                          |
|                 | Down             | 8x 01 04 04 03 FF          |                                          |
|                 | Direct           | 8x 01 04 44 00 00 0p 0q FF | pq: B Gain                               |
| CAM_AE          | Full Auto        | 8x 01 04 39 00 FF          | Automatic Exposure mode                  |
|                 | Manual           | 8x 01 04 39 03 FF          | Manual Control mode                      |
|                 | Shutter Priority | 8x 01 04 39 0A FF          | Shutter Priority Automatic Exposure mode |
|                 | Iris Priority    | 8x 01 04 39 0B FF          | Iris Priority Automatic Exposure mode    |
|                 | Bright           | 8x 01 04 39 0D FF          | Bright Mode (Manual control)             |
| CAM_SlowShutter | Auto             | 8x 01 04 5A 02 FF          | Auto Slow Shutter ON/OFF                 |
|                 | Manual           | 8x 01 04 5A 03 FF          |                                          |
| CAM_Shutter     | Reset            | 8x 01 04 0A 00 FF          | Shutter Setting                          |
|                 | Up               | 8x 01 04 0A 02 FF          |                                          |
|                 | Down             | 8x 01 04 0A 03 FF          |                                          |
|                 | Direct           | 8x 01 04 4A 00 00 0p 0q FF | pq: Shutter Position                     |
| CAM_Iris        | Reset            | 8x 01 04 0B 00 FF          | Iris Setting                             |
|                 | Up               | 8x 01 04 0B 02 FF          |                                          |
|                 | Down             | 8x 01 04 0B 03 FF          |                                          |
|                 | Direct           | 8x 01 04 4B 00 00 0p 0q FF | pq: Iris Position                        |
| CAM_Gain        | Reset            | 8x 01 04 0C 00 FF          | Gain Setting                             |
|                 | Up               | 8x 01 04 0C 02 FF          |                                          |
|                 | Down             | 8x 01 04 0C 03 FF          |                                          |
|                 | Direct           | 8x 01 04 4C 00 00 0p 0q FF | pq: Gain Position                        |
| CAM_Bright      | Reset            | 8x 01 04 0D 00 FF          | Bright Setting                           |
|                 | Up               | 8x 01 04 0D 02 FF          |                                          |
|                 | Down             | 8x 01 04 0D 03 FF          |                                          |
|                 | Direct           | 8x 01 04 4D 00 00 0p 0q FF | pq: Bright Position                      |
| CAM_ExpComp     | On               | 8x 01 04 3E 02 FF          | Exposure Compensation ON/OFF             |
|                 | Off              | 8x 01 04 3E 03 FF          |                                          |
|                 | Reset            | 8x 01 04 0E 00 FF          | Exposure Compensation Amount Setting     |
|                 | Up               | 8x 01 04 0E 02 FF          |                                          |
|                 | Down             | 8x 01 04 0E 03 FF          |                                          |
|                 | Direct           | 8x 01 04 4E 00 00 0p 0q FF | pq: ExpComp Position                     |
| CAM_Backlight   | On               | 8x 01 04 33 02 FF          | Back Light Compensation ON/OFF           |
|                 | Off              | 8x 01 04 33 03 FF          |                                          |
| CAM_SpotAE      | On               | 8x 01 04 59 02 FF          | Spot Automatic Exposure Setting          |
|                 | Off              | 8x 01 04 59 03 FF          |                                          |
|                 | Position         | 8x 01 04 29 0p 0q 0r 0s FF | pq: X (0 to F), rs: Y (0 to F)           |

# FCB Series Camera Command List (3/3)

| Command Set       | Command      | Command Packet                 | Comments                                  |
|-------------------|--------------|--------------------------------|-------------------------------------------|
| CAM_Aperture      | Reset        | 8x 01 04 02 00 FF              | Aperture Control                          |
|                   | Up           | 8x 01 04 02 02 FF              |                                           |
|                   | Down         | 8x 01 04 02 03 FF              |                                           |
|                   | Direct       | 8x 01 04 42 00 00 0p 0q FF     | pq: Aperture Gain                         |
| CAM_LR_Reverse    | On           | 8x 01 04 61 02 FF              | Mirror Image ON/OFF                       |
|                   | Off          | 8x 01 04 61 03 FF              |                                           |
| CAM_Freeze        | On           | 8x 01 04 62 02 FF              | Still Image ON/OFF                        |
|                   | Off          | 8x 01 04 62 03 FF              |                                           |
| CAM_PictureEffect | Off          | 8x 01 04 63 00 FF              | Picture Effect Setting                    |
|                   | Neg.Art      | 8x 01 04 63 02 FF              |                                           |
|                   | B&W          | 8x 01 04 63 04 FF              |                                           |
| CAM_Memory        | Reset        | 8x 01 04 3F 00 pp FF           | p: Memory Number (=0 to 5)                |
|                   | Set          | 8x 01 04 3F 01 pp FF           |                                           |
|                   | Recall       | 8x 01 04 3F 02 7F FF           |                                           |
| CAM_CUSTOM        | Reset        | 8x 01 04 3F 00 7F FF           | Starts in this mode at Power ON.          |
|                   | Set          | 8x 01 04 3F 01 7F FF           |                                           |
|                   | Recall       | 8x 01 04 3F 02 7F FF           |                                           |
| CAM_Display       | On           | 8x 01 04 15 02 FF              | Display ON/OFF                            |
|                   |              | (8x 01 06 06 02 FF)            |                                           |
|                   | Off          | 8x 01 04 15 03 FF              |                                           |
|                   |              | (8x 01 06 06 03 FF)            |                                           |
|                   | On/Off       | 8x 01 04 15 10 FF              |                                           |
|                   |              | (8x 01 06 06 10 FF)            |                                           |
| CAM_Date/TimeSet  | Date/TimeSet | 8x 01 04 70 0m 0n 0p 0q 0r 0s  | mn: Year (20mn)                           |
| _                 |              | Ot Ou Ov Ow FF                 | pq: Month, rs: Day                        |
|                   |              | (8x 01 07 29 0m 0n 0p 0q 0r 0s | tu: Hour, vw: Minute                      |
|                   |              | Ot Ou Ov Ow FF)                |                                           |
| CAM_DateDisplay   | On           | 8x 01 04 71 02 FF              | Date display ON/OFF                       |
|                   |              | (8x 01 07 2A 02 FF)            |                                           |
|                   | Off          | 8x 01 04 71 03 FF              |                                           |
|                   |              | (8x 01 07 2A 03 FF)            |                                           |
| CAM_TimeDisplay   | On           | 8x 01 04 72 02 FF              | Time display ON/OFF                       |
|                   |              | (8x 01 07 2B 02 FF)            |                                           |
|                   | Off          | 8x 01 04 72 03 FF              |                                           |
|                   |              | (8x 01 07 2B 03 FF)            |                                           |
| CAM_Title         | Title Set1   | 8x 01 04 73 00 mm nn pp        | mm: Vposition, nn: Hposition              |
|                   |              | qq 00 00 00 00 00 00 FF        | pp: Color, qq: Blink                      |
|                   | Title Set2   | 8x 01 04 73 01 mm nn pp        | mnpqrstuvw: Setting of Display Characters |
|                   |              | qq rr ss tt uu vv ww FF        | (1st to 10st Character)                   |
|                   | Title Set3   | 8x 01 04 73 02 mm nn pp        | mnpqrstuvw: Setting of Display Characters |
|                   |              | qq rr ss tt uu vv ww FF        | (11th to 20th Character)                  |
|                   | Title Clear  | 8x 01 04 74 00 FF              | Title Setting Clear                       |
|                   | On           | 8x 01 04 74 02 FF              | Title Display ON/OFF                      |
|                   | Off          | 8x 01 04 74 03 FF              | 1                                         |
| CAM_Mute          | On           | 8x 01 04 75 02 FF              | Mute ON/OFF                               |
|                   | Off          | 8x 01 04 75 03 FF              | 1                                         |
|                   | On/Off       | 8x 01 04 75 10 FF              | 1                                         |
| CAM_KEY Lock      | Off          | 8x 01 04 17 00 FF              | Camera control on/off                     |
|                   | On           | 8x 01 04 17 02 FF              | 1                                         |
| CA_ID Write       |              | 8x 01 04 22 0p 0q 0r 0s FF     | pqrs: Camera ID (0000~FFFF)               |

# FCB Series Camera Inquiry Command List (1/2)

| Inquiry Command        | Command Packet | Inquiry Packet       | Comments                        |
|------------------------|----------------|----------------------|---------------------------------|
| CAM_PowerInq           | 8x 09 04 00 FF | y0 50 02 FF          | On                              |
|                        |                | y0 50 03 FF          | Off                             |
| CAM_ZoomPosInq         | 8x 09 04 47 FF | y0 50 0p 0q 0r 0s FF | pqrs: Zoom Position             |
| CAM_DZoomModeInq       | 8x 09 04 06 FF | y0 50 02 FF          | D-Zoom On                       |
|                        |                | y0 50 03 FF          | D-Zoom Off                      |
| CAM_DZoomC/SModeInq    | 8x 09 04 36 FF | y0 50 00 FF          | Combine Mode                    |
|                        |                | y0 50 01 FF          | Separate Mode                   |
| CAM_DZoomPosInq        | 8x 09 04 46 FF | y0 50 00 00 0p 0q FF | pq: D-Zoom Position             |
| CAM_FocusModeInq       | 8x 09 04 38 FF | y0 50 02 FF          | Auto Focus                      |
|                        |                | y0 50 03 FF          | Manual Focus                    |
| CAM_FocusPosInq        | 8x 09 04 48 FF | y0 50 0p 0q 0r 0s FF | pqrs: Focus Position            |
| CAM_FocusNearLimitInq  | 8x 09 04 28 FF | y0 50 0p 0q 0r 0s FF | pqrs: Focus Near Limit Position |
| CAM_AFSensitivityInq   | 8x 09 04 58 FF | y0 50 02 FF          | AF Sensitivity Normal           |
|                        |                | y0 50 03 FF          | AF Sensitivity Low              |
| CAM_AFModeInq          | 8x 09 04 57 FF | y0 50 00 FF          | Normal AF                       |
|                        |                | y0 50 01 FF          | Interval AF                     |
|                        |                | y0 50 02 FF          | Zoom Trigger AF                 |
| CAM_AFTimeSettingInq   | 8x 09 04 27 FF | y0 50 0p 0q 0r 0s FF | pq: Movement Time, rs: Interval |
| CAM_WBModeInq          | 8x 09 04 35 FF | y0 50 00 FF          | Auto                            |
|                        |                | y0 50 01 FF          | In Door                         |
|                        |                | y0 50 02 FF          | Out Door                        |
|                        |                | y0 50 03 FF          | One Push WB                     |
|                        |                | y0 50 04 FF          | ATW                             |
|                        |                | y0 50 05 FF          | Manual                          |
| CAM_RGainInq           | 8x 09 04 43 FF | y0 50 00 00 0p 0q FF | pq: R Gain                      |
| CAM_BGainInq           | 8x 09 04 44 FF | y0 50 00 00 0p 0q FF | pq: B Gain                      |
| CAM_AEModeInq          | 8x 09 04 39 FF | y0 50 00 FF          | Full Auto                       |
|                        |                | y0 50 03 FF          | Manual                          |
|                        |                | y0 50 0A FF          | Shutter Priority                |
|                        |                | y0 50 0B FF          | Iris Priority                   |
|                        |                | y0 50 0D FF          | Bright                          |
| CAM_SlowShutterModeInq | 8x 09 04 5A FF | y0 50 02 FF          | Auto                            |
|                        |                | y0 50 03 FF          | Manual                          |
| CAM_ShutterPosInq      | 8x 09 04 4A FF | y0 50 00 00 0p 0q FF | pq: Shutter Position            |
| CAM_IrisPosInq         | 8x 09 04 4B FF | y0 50 00 00 0p 0q FF | pq: Iris Position               |
| CAM_GainPosInq         | 8x 09 04 4C FF | y0 50 00 00 0p 0q FF | pq: Gain Position               |
| CAM_BrightPosInq       | 8x 09 04 4D FF | y0 50 00 00 0p 0q FF | pq: Bright Position             |
| CAM_ExpCompModeInq     | 8x 09 04 3E FF | y0 50 02 FF          | On                              |
|                        |                | y0 50 03 FF          | Off                             |
| CAM_ExpCompPosInq      | 8x 09 04 4E FF | y0 50 00 00 0p 0q FF | pq: ExpComp Position            |
| CAM_BacklightModeInq   | 8x 09 04 33 FF | y0 50 02 FF          | On                              |
|                        |                | y0 50 03 FF          | Off                             |
| CAM_SpotAEModeInq      | 8x 09 04 59 FF | y0 50 02 FF          | On                              |
|                        |                | y0 50 03 FF          | Off                             |
| CAM_SpotAEPosInq       | 8x 09 04 29 FF | y0 50 0p 0q 0r 0s FF | pq: X position, rs: Y position  |
| CAM_ApertureInq        | 8x 09 04 42 FF | y0 50 00 00 0p 0q FF | pq: Aperture Gain               |

# FCB Series Camera Inquiry Command List (2/2)

| Inquiry Command          | Command Packet   | Inquiry Packet       | Comments                   |
|--------------------------|------------------|----------------------|----------------------------|
| CAM_LR_ReverseModeInq    | 8x 09 04 61 FF   | y0 50 02 FF          | On                         |
|                          |                  | y0 50 03 FF          | Off                        |
| CAM_FreezeModeInq        | 8x 09 04 62 FF   | y0 50 02 FF          | On                         |
|                          |                  | y0 50 03 FF          | Off                        |
| CAM_PictureEffectModeInq | 8x 09 04 63 FF   | y0 50 00 FF          | Off                        |
|                          |                  | y0 50 02 FF          | Neg.Art                    |
|                          |                  | y0 50 04 FF          | B&W                        |
| CAM_MemoryInq            | 8x 09 04 3F FF   | y0 50 pp FF          | pp: Last Recall Memory No. |
| CAM_DisplayModeInq       | 8x 09 04 15 FF   | y0 50 02 FF          | On                         |
|                          | (8x 09 06 06 FF) | y0 50 03 FF          | Off                        |
| CAM_TitleDisplayModeInq  | 8x 09 04 74 FF   | y0 50 02 FF          | On                         |
|                          |                  | y0 50 03 FF          | Off                        |
| CAM_MuteModeInq          | 8x 09 04 75 FF   | y0 50 02 FF          | On                         |
|                          |                  | y0 50 03 FF          | Off                        |
| CAM_KeyLockInq           | 8x 09 04 17 FF   | y0 50 00 FF          | Off                        |
|                          |                  | y0 50 02 FF          | On                         |
| CAM_IDInq                | 8x 09 04 22 FF   | y0 50 0p 0q 0r 0s FF | pqrs: Camera ID            |

# **FCB Series Camera Block Inquiry Command List**

# Lens Control System Inquiry Commands (1/2) ..... Command Packet 8x 09 7E 7E 00 FF

| Byte | Bit | Comments                   |
|------|-----|----------------------------|
|      | 7   |                            |
|      | 6   |                            |
|      | 5   | Destination Address        |
|      | 4   |                            |
| 0    | 3   |                            |
|      | 2   |                            |
|      | 1   | Source Address             |
|      | 0   |                            |
|      | 7   | 0 Completion Message (50h) |
|      | 6   | 1                          |
|      | 5   | 0                          |
|      | 4   | 1                          |
| 1    | 3   | 0                          |
|      | 2   | 0                          |
|      | 1   | 0                          |
|      | 0   | 0                          |
|      | 7   | 0                          |
|      | 6   | 0                          |
|      | 5   | 0                          |
|      | 4   | 0                          |
| 2    | 3   |                            |
|      | 2   | -                          |
|      | 1   | Zoom Position (HH)         |
|      | 0   | _                          |
|      | 7   | 0                          |
|      | 6   | 0                          |
|      | 5   | 0                          |
|      | 4   | 0                          |
| 3    | 3   |                            |
|      | 2   |                            |
|      | 1   | Zoom Position (HL)         |
|      | 0   |                            |
|      | 7   | 0                          |
|      | 6   | 0                          |
|      | 5   | 0                          |
|      | 4   | 0                          |
| 4    | 3   |                            |
|      | 2   |                            |
|      | 1   | Zoom Position (LH)         |
|      | 0   |                            |
|      | 7   | 0                          |
|      | 6   | 0                          |
|      | 5   | 0                          |
|      | 4   | 0                          |
| 5    | 3   |                            |
|      | 2   |                            |
|      | 1   | Zoom Position (LL)         |
|      | 0   |                            |
|      |     |                            |

| Byte | Bit | Comments             |
|------|-----|----------------------|
|      | 7   | 0                    |
| İ    | 6   | 0                    |
|      | 5   | 0                    |
|      | 4   | 0                    |
| 6    | 3   |                      |
| ĺ    | 2   | F N 1: ://ID         |
|      | 1   | Focus Near Limit (H) |
|      | 0   |                      |
|      | 7   | 0                    |
|      | 6   | 0                    |
|      | 5   | 0                    |
| _    | 4   | 0                    |
| 7    | 3   |                      |
|      | 2   |                      |
|      | 1   | Focus Near Limit (L) |
|      | 0   | 1                    |
|      | 7   | 0                    |
|      | 6   | 0                    |
|      | 5   | 0                    |
|      | 4   | 0                    |
| 8    | 3   |                      |
|      | 2   |                      |
|      | 1   | Focus Position (HH)  |
|      | 0   |                      |
|      | 7   | 0                    |
|      | 6   | 0                    |
|      | 5   | 0                    |
|      | 4   | 0                    |
| 9    | 3   |                      |
|      | 2   | Focus Position (HL)  |
|      | 1   |                      |
|      | 0   |                      |
|      | 7   | 0                    |
|      | 6   | 0                    |
| Ì    | 5   | 0                    |
|      | 4   | 0                    |
| 10   | 3   |                      |
|      | 2   | 1                    |
|      | 1   | Focus Position (LH)  |
|      | 0   | 1                    |
|      | 7   | 0                    |
|      | 6   | 0                    |
|      | 5   | 0                    |
|      | 4   | 0                    |
| 11   | 3   | , ,                  |
|      |     | -                    |
|      | 2   |                      |
|      | 2   | Focus Position (LL)  |

# Lens Control System Inquiry Commands (2/2) ..... Command Packet 8x 09 7E 7E 00 FF

| Byte | Bit | Comments                                     |
|------|-----|----------------------------------------------|
|      | 7   | 0                                            |
|      | 6   | 0                                            |
|      | 5   | 0                                            |
| 10   | 4   | 0                                            |
| 12   | 3   | 0                                            |
|      | 2   | 0                                            |
|      | 1   | 0                                            |
|      | 0   | 0                                            |
|      | 7   | 0                                            |
|      | 6   | 0                                            |
|      | 5   | DZoomMode 1: Separate 0: Combine             |
| 13   | 4   | AF Mode                                      |
| 13   | 3   | 0: Normal 1: Interval 2: Zoom Trigger        |
|      | 2   | AF Sensitivity 1: Normal 0: Slow             |
|      | 1   | Digital Zoom 1:On 0:Off                      |
|      | 0   | Focus Mode 1:Auto 0:Manual                   |
|      | 7   | 0                                            |
|      | 6   | 0                                            |
|      | 5   | 0                                            |
| 14   | 4   | 0                                            |
| 14   | 3   | Low Contrast Detection 1: Yes 0: No          |
|      | 2   | Camera Memory Recall 1: Executing 0: Stopped |
|      | 1   | Focus Command 1: Executing 0: Stopped        |
|      | 0   | Zoom Command 1: Executing 0: Stopped         |
|      | 7   | 1 Terminator (FFh)                           |
|      | 6   | 1                                            |
|      | 5   | 1                                            |
| 1.5  | 4   | 1                                            |
| 15   | 3   | 1                                            |
|      | 2   | 1                                            |
|      | 1   | 1                                            |
|      | 0   | 1                                            |

# Camera Control System Inquiry Commands (1/2)... Command Packet 8x 09 7E 7E 01 FF

| Byte | Bit | Comments                   |
|------|-----|----------------------------|
|      | 7   |                            |
|      | 6   | Destination Address        |
|      | 5   | Destination Address        |
| 0    | 4   |                            |
| 0    | 3   |                            |
|      | 2   | Source Address             |
|      | 1   | Source Address             |
|      | 0   |                            |
|      | 7   | 0 Completion Message (50h) |
|      | 6   | 1                          |
|      | 5   | 0                          |
| 1    | 4   | 1                          |
| 1    | 3   | 0                          |
|      | 2   | 0                          |
|      | 1   | 0                          |
|      | 0   | 0                          |
|      | 7   | 0                          |
|      | 6   | 0                          |
|      | 5   | 0                          |
| 2    | 4   | 0                          |
| 2    | 3   |                            |
|      | 2   | D.C.:. (II)                |
|      | 1   | R Gain (H)                 |
|      | 0   |                            |
|      | 7   | 0                          |
|      | 6   | 0                          |
|      | 5   | 0                          |
| 3    | 4   | 0                          |
|      | 3   |                            |
|      | 2   | R Gain (L)                 |
|      | 1   | R Gain (L)                 |
|      | 0   |                            |
|      | 7   | 0                          |
|      | 6   | 0                          |
|      | 5   | 0                          |
| 4    | 4   | 0                          |
|      | 3   |                            |
|      | 2   | B Gain (H)                 |
|      | 1   | 2 5 (12)                   |
|      | 0   |                            |
|      | 7   | 0                          |
|      | 6   | 0                          |
|      | 5   | 0                          |
| 5    | 4   | 0                          |
|      | 3   |                            |
|      | 2   | B Gain (L)                 |
|      | 1   | D Gain (L)                 |
|      | 0   |                            |

| Byte | Bit | Comments                     |
|------|-----|------------------------------|
|      | 7   | 0                            |
|      | 6   | 0                            |
|      | 5   | 0                            |
|      | 4   | 0                            |
| 6    | 3   | 0                            |
|      | 2   |                              |
|      | 1   | WB Mode                      |
|      | 0   |                              |
|      | 7   | 0                            |
|      | 6   | 0                            |
|      | 5   | 0                            |
| 7    | 4   | 0                            |
| 7    | 3   |                              |
|      | 2   | A mantana Caim               |
|      | 1   | Aperture Gain                |
|      | 0   |                              |
|      | 7   | 0                            |
|      | 6   | 0                            |
|      | 5   | 0                            |
| 8    | 4   |                              |
| 8    | 3   |                              |
|      | 2   | Exposure Mode                |
|      | 1   |                              |
|      | 0   |                              |
|      | 7   | 0                            |
|      | 6   | 0                            |
|      | 5   | 0                            |
| 9    | 4   | 0                            |
| 9    | 3   | Spot AE 1: On 0: Off         |
|      | 2   | Back Light 1:On 0:Off        |
|      | 1   | Exposure Comp. 1:On 0:Off    |
|      | 0   | Slow Shutter 1:Auto 0:Manual |
|      | 7   | 0                            |
|      | 6   | 0                            |
|      | 5   | 0                            |
| 10   | 4   |                              |
|      | 3   |                              |
|      | 2   | Shutter Position             |
|      | 1   |                              |
|      | 0   |                              |
|      | 7   | 0                            |
|      | 6   | 0                            |
|      | 5   | 0                            |
| 11   | 4   |                              |
|      | 3   |                              |
|      | 2   | Iris Position                |
|      | 1   |                              |
|      | 0   |                              |

# Camera Control System Inquiry Commands (2/2)... Command Packet 8x 09 7E 7E 01 FF

| Byte | Bit | Comments                |
|------|-----|-------------------------|
|      | 7   | 0                       |
|      | 6   | 0                       |
|      | 5   | 0                       |
| 10   | 4   | 0                       |
| 12   | 3   |                         |
|      | 2   | Gain Position           |
|      | 1   | Gain Position           |
|      | 0   |                         |
|      | 7   | 0                       |
|      | 6   | 0                       |
|      | 5   | 0                       |
| 13   | 4   |                         |
| 13   | 3   |                         |
|      | 2   | Bright Position         |
|      | 1   |                         |
|      | 0   |                         |
|      | 7   | 0                       |
|      | 6   | 0                       |
|      | 5   | 0                       |
| 14   | 4   | 0                       |
| 14   | 3   |                         |
|      | 2   | Exposure Comp. Position |
|      | 1   | Exposure Comp. Fosition |
|      | 0   |                         |
|      | 7   | 1 Terminator (FFh)      |
|      | 6   | 1                       |
|      | 5   | 1                       |
| 15   | 4   | 1                       |
| 13   | 3   | 1                       |
|      | 2   | 1                       |
|      | 1   | 1                       |
|      | 0   | 1                       |

# Other Inquiry Commands (1/2)......Command Packet 8x 09 7E 7E 02 FF

| Byte | Bit | Comments                   |  |  |  |  |
|------|-----|----------------------------|--|--|--|--|
|      | 7   |                            |  |  |  |  |
|      | 6   | D. C. C. All               |  |  |  |  |
|      | 5   | Destination Address        |  |  |  |  |
|      | 4   |                            |  |  |  |  |
| 0    | 3   |                            |  |  |  |  |
|      | 2   | C Address                  |  |  |  |  |
|      | 1   | Source Address             |  |  |  |  |
|      | 0   |                            |  |  |  |  |
|      | 7   | 0 Completion Message (50h) |  |  |  |  |
|      | 6   | 1                          |  |  |  |  |
|      | 5   | 0                          |  |  |  |  |
| 1    | 4   | 1                          |  |  |  |  |
| 1    | 3   | 0                          |  |  |  |  |
|      | 2   | 0                          |  |  |  |  |
|      | 1   | 0                          |  |  |  |  |
|      | 0   | 0                          |  |  |  |  |
|      | 7   | 0                          |  |  |  |  |
|      | 6   | 0                          |  |  |  |  |
|      | 5   | 0                          |  |  |  |  |
| 2    | 4   | 0                          |  |  |  |  |
|      | 3   | 0                          |  |  |  |  |
|      | 2   | 0                          |  |  |  |  |
|      | 1   | Key Lock 1: On 0: Off      |  |  |  |  |
|      | 0   | Power 1:On 0:Off           |  |  |  |  |
|      | 7   | 0                          |  |  |  |  |
|      | 6   | 0                          |  |  |  |  |
|      | 5   | 0                          |  |  |  |  |
| 3    | 4   | 0                          |  |  |  |  |
|      | 3   | Freeze 1:On 0:Off          |  |  |  |  |
|      | 2   | LR Reverse 1:On 0:Off      |  |  |  |  |
|      | 1   | 0                          |  |  |  |  |
|      | 0   | 0                          |  |  |  |  |
|      | 7   | 0                          |  |  |  |  |
|      | 6   | 0                          |  |  |  |  |
|      | 5   | 0                          |  |  |  |  |
| 4    | 4   | Mute 1: On 0: Off          |  |  |  |  |
|      | 3   | Title Display 1: On 0: Off |  |  |  |  |
|      | 2   | Display 1: On 0: Off       |  |  |  |  |
|      | 1   | 0                          |  |  |  |  |
|      | 0   | 0                          |  |  |  |  |
|      | 7   | 0                          |  |  |  |  |
|      | 6   | 0                          |  |  |  |  |
|      | 5   | 0                          |  |  |  |  |
| 5    | 4   | 0                          |  |  |  |  |
|      | 3   |                            |  |  |  |  |
|      | 2   | Picture Effect Mode        |  |  |  |  |
|      | 1   |                            |  |  |  |  |
|      | 0   |                            |  |  |  |  |

| Byte | Bit | Comments       |
|------|-----|----------------|
|      | 7   | 0              |
|      | 6   | 0              |
|      | 5   | 0              |
|      | 4   | 0              |
| 6    | 3   | 0              |
|      | 2   | 0              |
|      | 1   | 0              |
|      | 0   | 0              |
|      | 7   | 0              |
|      | 6   | 0              |
|      | 5   | 0              |
| _    | 4   | 0              |
| 7    | 3   | 0              |
|      | 2   | 0              |
|      | 1   | 0              |
|      | 0   | 0              |
|      | 7   | 0              |
|      | 6   | 0              |
|      | 5   | 0              |
|      | 4   | 0              |
| 8    | 3   |                |
|      | 2   |                |
|      | 1   | Camera ID (HH) |
|      | 0   |                |
|      | 7   | 0              |
|      | 6   | 0              |
|      | 5   | 0              |
|      | 4   | 0              |
| 9    | 3   |                |
|      | 2   | _              |
|      | 1   | Camera ID (HL) |
|      | 0   | -              |
|      | 7   | 0              |
|      | 6   | 0              |
|      | 5   | 0              |
|      | 4   | 0              |
| 10   | 3   |                |
|      | 2   | -              |
|      | 1   | Camera ID (LH) |
|      | 0   | -              |
|      | 7   | 0              |
|      | 6   | 0              |
|      | 5   | 0              |
|      | 4   | 0              |
| 11   | 3   | U              |
|      |     | -              |
|      | 2   | Camera ID (LL) |
|      | 1   | -              |
|      | 0   |                |

# Other Inquiry Commands (2/2)......Command Packet 8x 09 7E 7E 02 FF

| Byte | Bit | Comments                                  |  |  |  |
|------|-----|-------------------------------------------|--|--|--|
|      | 7   | 0                                         |  |  |  |
|      | 6   | 0                                         |  |  |  |
|      | 5   | External Lock 1: Provided 0: Not provided |  |  |  |
| 10   | 4   | Memory 1: Provided 0: Not provided        |  |  |  |
| 12   | 3   | Clock 1: Provided 0: Not provided         |  |  |  |
|      | 2   | 0                                         |  |  |  |
|      | 1   | 0                                         |  |  |  |
|      | 0   | System 1:PAL 0:NTSC                       |  |  |  |
|      | 7   | 0                                         |  |  |  |
|      | 6   | 0                                         |  |  |  |
|      | 5   | 0                                         |  |  |  |
| 13   | 4   | 0                                         |  |  |  |
| 15   | 3   |                                           |  |  |  |
|      | 2   | V-Phase (H)                               |  |  |  |
|      | 1   | v-rhase (n)                               |  |  |  |
|      | 0   |                                           |  |  |  |
|      | 7   | 0                                         |  |  |  |
|      | 6   | 0                                         |  |  |  |
|      | 5   | 0                                         |  |  |  |
| 14   | 4   | 0                                         |  |  |  |
| 14   | 3   |                                           |  |  |  |
|      | 2   | V-Phase (L)                               |  |  |  |
|      | 1   | V-rhase (L)                               |  |  |  |
|      | 0   |                                           |  |  |  |
|      | 7   | 1 Terminator (FFh)                        |  |  |  |
|      | 6   | 1                                         |  |  |  |
|      | 5   | 1                                         |  |  |  |
| 15   | 4   | 1                                         |  |  |  |
| 13   | 3   | 1                                         |  |  |  |
|      | 2   | 1                                         |  |  |  |
|      | 1   | 1                                         |  |  |  |
|      | 0   | 1                                         |  |  |  |

# Enlargement Function Query Command (1/2)...... Command Packet 8x 09 7E 7E 03 FF

| Byte | Bit | Comments                   |  |  |  |
|------|-----|----------------------------|--|--|--|
|      | 7   |                            |  |  |  |
|      | 6   | Destination Address        |  |  |  |
|      | 5   | Destination Address        |  |  |  |
|      | 4   |                            |  |  |  |
| 0    | 3   |                            |  |  |  |
|      | 2   | G A 11                     |  |  |  |
|      | 1   | Source Address             |  |  |  |
|      | 0   |                            |  |  |  |
|      | 7   | 0 Completion Message (50h) |  |  |  |
|      | 6   | 1                          |  |  |  |
|      | 5   | 0                          |  |  |  |
| 1    | 4   | 1                          |  |  |  |
| 1    | 3   | 0                          |  |  |  |
|      | 2   | 0                          |  |  |  |
|      | 1   | 0                          |  |  |  |
|      | 0   | 0                          |  |  |  |
|      | 7   | 0                          |  |  |  |
|      | 6   | 0                          |  |  |  |
|      | 5   | 0                          |  |  |  |
| 2    | 4   | 0                          |  |  |  |
|      | 3   |                            |  |  |  |
|      | 2   | D: : 17                    |  |  |  |
|      | 1   | Digital Zoom Position (H)  |  |  |  |
|      | 0   |                            |  |  |  |
|      | 7   | 0                          |  |  |  |
|      | 6   | 0                          |  |  |  |
|      | 5   | 0                          |  |  |  |
| 3    | 4   | 0                          |  |  |  |
|      | 3   |                            |  |  |  |
|      | 2   | Digital Zoom Position (L)  |  |  |  |
|      | 1   | Digital Zoom Position (L)  |  |  |  |
|      | 0   |                            |  |  |  |
|      | 7   | 0                          |  |  |  |
|      | 6   | 0                          |  |  |  |
|      | 5   | 0                          |  |  |  |
| 4    | 4   | 0                          |  |  |  |
|      | 3   |                            |  |  |  |
|      | 2   | AF Activation Time (H)     |  |  |  |
|      | 1   | 711 Ted vadon Time (II)    |  |  |  |
|      | 0   |                            |  |  |  |
|      | 7   | 0                          |  |  |  |
|      | 6   | 0                          |  |  |  |
|      | 5   | 0                          |  |  |  |
| 5    | 4   | 0                          |  |  |  |
|      | 3   |                            |  |  |  |
|      | 2   | AF Activation Time (L)     |  |  |  |
|      | 1   | 74 Activation Time (L)     |  |  |  |
|      | 0   |                            |  |  |  |
|      |     |                            |  |  |  |

| Byte | Bit         | Comments              |
|------|-------------|-----------------------|
|      | 7           | 0                     |
| 6    | 6           | 0                     |
|      | 5           | 0                     |
|      | 4           | 0                     |
| U    | 3           |                       |
|      | 2           | AF Interval Time (H)  |
|      | 1           | Ar mervar time (n)    |
|      | 0           |                       |
|      | 7           | 0                     |
|      | 6           | 0                     |
|      | 5           | 0                     |
| 7    | 4           | 0                     |
| ,    | 3           |                       |
|      | 2           | AE Interval Time (I.) |
|      | 1           | AF Interval Time (L)  |
|      | 0           |                       |
|      | 7           | 0                     |
|      | 6           | 0                     |
|      | 5           | 0                     |
| 0    | 4           | 0                     |
| 8    | 3           |                       |
|      | 2           |                       |
|      | 1           | SpotAE Position (X)   |
|      | 0           |                       |
|      | 7           | 0                     |
|      | 6           | 0                     |
|      | 5           | 0                     |
|      | 4           | 0                     |
| 9    | 3           |                       |
|      | 2           |                       |
|      | 1           | SpotAE Position (Y)   |
|      | 0           |                       |
|      | 7           | 0                     |
|      | 6           | 0                     |
|      | 5           | 0                     |
| 10   | 4           | 0                     |
| 10   | 3           | 0                     |
|      | 2           | 0                     |
|      | 1           | 0                     |
|      | 0           | 0                     |
|      | 7           | 0                     |
|      |             | 0                     |
|      | 6           |                       |
|      |             |                       |
|      | 5           | 0                     |
| 11   | 5<br>4      | 0                     |
| 11   | 5<br>4<br>3 | 0<br>0<br>0           |
| 11   | 5<br>4      | 0                     |

# Enlargement Function Query Command (2/2)...... Command Packet 8x 09 7E 7E 03 FF

| Byte | Bit | Comments           |
|------|-----|--------------------|
|      | 7   | 0                  |
|      | 6   | 0                  |
|      | 5   | 0                  |
| 12   | 4   | 0                  |
| 12   | 3   | 0                  |
|      | 2   | 0                  |
|      | 1   | 0                  |
|      | 0   | 0                  |
|      | 7   | 0                  |
|      | 6   | 0                  |
|      | 5   | 0                  |
| 1.0  | 4   | 0                  |
| 13   | 3   | 0                  |
|      | 2   | 0                  |
|      | 1   | 0                  |
|      | 0   | 0                  |
|      | 7   | 0                  |
|      | 6   | 0                  |
|      | 5   | 0                  |
| 1.4  | 4   | 0                  |
| 14   | 3   | 0                  |
|      | 2   | 0                  |
|      | 1   | 0                  |
|      | 0   | 0                  |
|      | 7   | 1 Terminator (FFh) |
|      | 6   | 1                  |
|      | 5   | 1                  |
| 1.5  | 4   | 1                  |
| 15   | 3   | 1                  |
|      | 2   | 1                  |
|      | 1   | 1                  |
|      | 0   | 1                  |

# **VISCA Command Setting Values**

# Exposure Control (1/2)

|               |    | NTSC  | PAL   |
|---------------|----|-------|-------|
| Shutter Speed | 15 | 10000 | 10000 |
|               | 14 | 6000  | 6000  |
|               | 13 | 4000  | 3500  |
|               | 12 | 3000  | 2500  |
|               | 11 | 2000  | 1750  |
|               | 10 | 1500  | 1250  |
|               | 0F | 1000  | 1000  |
|               | 0E | 725   | 600   |
|               | 0D | 500   | 425   |
|               | 0C | 350   | 300   |
|               | 0B | 250   | 215   |
|               | 0A | 180   | 150   |
|               | 09 | 125   | 120   |
|               | 08 | 100   | 100   |
|               | 07 | 90    | 75    |
|               | 06 | 60    | 50    |
|               | 05 | 30    | 25    |
|               | 04 | 15    | 12    |
|               | 03 | 8     | 6     |
|               | 02 | 4     | 3     |
|               | 01 | 2     | 2     |
|               | 00 | 1     | 1     |
| Iris          | 11 | F1.8  |       |
|               | 10 | F2.0  |       |
|               | 0F | F2.4  |       |
|               | 0E | F2.8  |       |
|               | 0D | F3.4  |       |
|               | 0C | F4.0  |       |
|               | 0B | F4.8  |       |
|               | 0A | F5.6  |       |
|               | 09 | F6.8  |       |
|               | 08 | F8.0  |       |
|               | 07 | F9.6  |       |
|               | 06 | F11   |       |
|               | 05 | F14   |       |
|               | 04 | F16   |       |
|               | 03 | F19   |       |
|               | 02 | F22   |       |
|               | 01 | F28   |       |
|               | 00 | CLOSE |       |
|               | 1  | 1     |       |

| 0F | 28 dB                                                                            |
|----|----------------------------------------------------------------------------------|
| 0E | 26 dB                                                                            |
| 0D | 24 dB                                                                            |
| 0C | 22 dB                                                                            |
| 0B | 20 dB                                                                            |
| 0A | 18 dB                                                                            |
| 09 | 16 dB                                                                            |
| 08 | 14 dB                                                                            |
| 07 | 12 dB                                                                            |
| 06 | 10 dB                                                                            |
| 05 | 8 dB                                                                             |
| 04 | 6 dB                                                                             |
| 03 | 4 dB                                                                             |
| 02 | +2 dB                                                                            |
| 01 | 0                                                                                |
| 00 | −3 dB                                                                            |
|    | 0E<br>0D<br>0C<br>0B<br>0A<br>09<br>08<br>07<br>06<br>05<br>04<br>03<br>02<br>01 |

# **Exposure Control (2/2)**

|                |    | IRIS  | GAIN     |
|----------------|----|-------|----------|
| Bright         | 1F | F1.8  | 28 dB    |
|                | 1E | F1.8  | 26 dB    |
|                | 1D | F1.8  | 24 dB    |
|                | 1C | F1.8  | 22 dB    |
|                | 1B | F1.8  | 20 dB    |
|                | 1A | F1.8  | 18 dB    |
|                | 19 | F1.8  | 16 dB    |
|                | 18 | F1.8  | 14 dB    |
|                | 17 | F1.8  | 12 dB    |
|                | 16 | F1.8  | 10 dB    |
|                | 15 | F1.8  | 8 dB     |
|                | 14 | F1.8  | 6 dB     |
|                | 13 | F1.8  | 4 dB     |
|                | 12 | F1.8  | 2 dB     |
|                | 11 | F1.8  | 0        |
|                | 10 | F2.0  | 0        |
|                | 0F | F2.4  | 0        |
|                | 0E | F2.8  | 0        |
|                | 0D | F3.4  | 0        |
|                | 0C | F4.0  | 0        |
|                | 0B | F4.8  | 0        |
|                | 0A | F5.6  | 0        |
|                | 09 | F6.8  | 0        |
|                | 08 | F8.0  | 0        |
|                | 07 | F9.6  | 0        |
|                | 06 | F11   | 0        |
|                | 05 | F14   | 0        |
|                | 04 | F16   | 0        |
|                | 03 | F19   | 0        |
|                | 02 | F22   | 0        |
|                | 01 | F28   | 0        |
|                | 00 | CLOSE | 0        |
| Exposure Comp. | 0E | 7     | 10.5 dB  |
|                | 0D | 6     | 9 dB     |
|                | 0C | 5     | 7.5 dB   |
|                | 0B | 4     | 6 dB     |
|                | 0A | 3     | 4.5 dB   |
|                | 09 | 2     | 3 dB     |
|                | 08 | 1     | 1.5 dB   |
|                | 07 | 0     | 0 dB     |
|                | 06 | -1    | -1.5 dB  |
|                | 05 | -2    | -3 dB    |
|                | 04 | -3    | -4.5 dB  |
|                | 03 | -4    | -6 dB    |
|                | 02 | -5    | -7.5 dB  |
|                | 01 | -6    | −9 dB    |
|                | 00 | -7    | -10.5 dB |

# Zoom Ratio and Zoom Position (for reference)

| Zoom Ratio<br>×10 Lens | Optical Zoom Position Data |
|------------------------|----------------------------|
| ×1                     | 0000                       |
| ×2                     | 188E                       |
| ×3                     | 2507                       |
| ×4                     | 2082                       |
| ×5                     | 3130                       |
| ×6                     | 352E                       |
| ×7                     | 385D                       |
| ×8                     | 3B48                       |
| ×9                     | 3E01                       |
| ×10                    | 4000                       |

|                       | X10-NISC                      | X10-PAL                       |
|-----------------------|-------------------------------|-------------------------------|
| Digital Zoom<br>Ratio | Digital Zoom<br>Position Data | Digital Zoom<br>Position Data |
| ×1                    | 4000                          | 4000                          |
| ×2                    | 6000                          | 5E80                          |
| ×3                    | 6A80                          | 6880                          |
| ×4                    | 7000                          | 6DC0                          |

# **Lens Control**

| 7 D:4:           | 0000         | to | 4000                        | to      | 7000             |
|------------------|--------------|----|-----------------------------|---------|------------------|
| Zoom Position    | Wide end     | Op | tical Tele e                | nd      | Digital Tele end |
| E D W            | 1000         | to | C000                        |         |                  |
| Focus Position   | Far end      |    | Near end                    |         |                  |
|                  | 1000: Over I | nf |                             |         |                  |
|                  | 2000: 8.0 m  |    |                             |         |                  |
|                  | 3000: 3.5 m  |    |                             |         |                  |
|                  | 4000: 2.0 m  |    | As the distance on the left |         |                  |
|                  | 5000: 1.4 m  |    | will diffe                  | er due  | to temperature   |
| EN1::4           | 6000: 1 m    |    | characte                    | ristics | s, etc., use as  |
| Focus Near Limit | 7000: 80 cm  |    | approxir                    | nate v  | alues.           |
|                  | 8000: 29 cm  |    | * The lo                    | wer 1   | byte is fixed at |
|                  | 9000: 10 cm  |    | 00.                         |         |                  |
|                  | A000: 4.7 cn | 1  |                             |         |                  |
|                  | B000: 2.3 cm | 1  |                             |         |                  |
|                  | C000: 1.0 cm | ı  |                             |         |                  |

# Others

| R,B gain | 00~FF |
|----------|-------|
| Aperture | 00~0F |

# Title Setting

| Vposition | 00 to 0A           |        |  |
|-----------|--------------------|--------|--|
| Hposition | 00 to 17           |        |  |
| D         | 00: Does not blink |        |  |
| Blink     | 01: Blinks         |        |  |
|           | 00                 | White  |  |
| Color     | 01                 | Yellow |  |
|           | 02                 | Violet |  |
|           | 03                 | Red    |  |
|           | 04                 | Cyan   |  |
|           | 05                 | Green  |  |
|           | 06                 | Blue   |  |

| 00 | 01 | 02 | 03 | 04 | 05 | 06 | 07 |
|----|----|----|----|----|----|----|----|
| A  | В  | C  | D  | Е  | F  | G  | Н  |
| 08 | 09 | 0a | 0b | 0c | 0d | 0e | 0f |
| I  | J  | K  | L  | M  | N  | О  | P  |
| 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |
| Q  | R  | S  | T  | U  | V  | W  | X  |
| 18 | 19 | 1a | 1b | 1c | 1d | 1e | 1f |
| Y  | Z  | &  |    | ?  | !  | 1  | 2  |
| 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |
| 3  | 4  | 5  | 6  | 7  | 8  | 9  | 0  |
| 28 | 29 | 2a | 2b | 2c | 2d | 2e | 2f |
| À  | È  | Ì  | Ó  | Ù  | Á  | É  | Í  |
| 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 |
| Ó  | Ú  | Â  | Ê  | Ô  | Æ  | Œ  | Ã  |
| 38 | 39 | 3a | 3b | 3c | 3d | 3e | 3f |
| Õ  | Ñ  | Ç  | В  | Ä  | Ϊ  | Ö  | Ü  |
| 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 |
| Å  | \$ | ₽  | ¥  | DM | £  | i  | i  |
| 48 | 49 | 4a | 4b | 4c | 4d | 4e | 4f |
| ø  | "  | :  | 4  |    | ,  | /  | -  |
|    |    |    |    |    |    |    |    |

# **Specifications**

Image sensor 1/4 type EX-view HAD CCD

Picture elements FCB-IX11A: Approx. 380K pixels

 $(768 (H) \times 494 (V))$ 

FCB-IX11AP: Approx. 440K pixels

 $(752 (H) \times 582 (V))$ 

Horizontal resolution

NTSC: 470 TV lines (WIDE end)

PAL: 460 TV lines (WIDE end)

Lens  $10 \times zoom$ 

f= 4.2 mm (WIDE) to 42 mm (TELE), F1.8 to F2.9

Zoom movement speed

Optical WIDE/Optical TELE 1.8 s Optical WIDE/Digital TELE 3.5 s Digital WIDE/Digital TELE 1.7 s  $\infty$  to Near 0.5 s

Digital zoom  $4 \times (40 \times \text{ with optical zoom})$ 

Angle of view (H)

46 degree (WIDE end) to 4.6 degree

(TELE end)

Min. working distance

10 mm (WIDE end), 1000 mm

(TELE end)

Sync system Internal

Min. illumination

1.5 lux (F1.8, <sup>1</sup>/<sub>60</sub> s (NTSC) or <sup>1</sup>/<sub>50</sub> s

(PAL))

0.10 lux (F1.8,  $^{1}/_{4}$  s (NTSC) or  $^{1}/_{3}$  s

(PAL))

Recommended illumination

100 to 100,000 lux

S/N ratio 50 dB or more

Back light compensation

ON/OFF

Electronic shutter speed

<sup>1</sup>/<sub>1</sub> to <sup>1</sup>/<sub>10,000</sub> s (22 steps)

White balance AUTO, ATW, Indoor, Outdoor,

One Push WB, Manual WB

Gain Auto/Manual (-3 to 28 dB, 2 dB

steps)

Aperture control 16 steps

Focus Auto (H, L), On-Push AF, Manual,

Infinity

Interval AF, Zoom Trigger AF

Preset 6 positions

Serial interface VISCA protocol (TTL/RS-232C

signal level)

9.6 Kbps, 19.2 Kbps, 38.4 Kbps, Stop bit, 1/2 bit (switchable)

Video Output VBS: 1.0 Vp-p (Sync negative),

Y/C Output

Storage temperature/Humidity

-20 to 60 °C (-4 to 140 °F)/20 to 95 %

Operating temperature/Humidity

0 to 50 °C (32 to 122 °F)/20 to 80 %

Power requirements/Power consumption

6 to 12 V DC/1.6 W (2.0 W with

active motors)

Weight 95 g (3 oz.)

Dimensions  $39.3 \times 44.8 \times 65.0 \text{ mm}$ 


 $(1^{9}/_{16} \times 1^{13}/_{16} \times 2^{5}/_{8} \text{ in.}) (\text{w/h/d})$ 

Design and specifications are subject to change without notice.


42

# **Dimensions**







# Left side




# Top



# **Bottom**





# Rear



Unit: mm (inches)

# Pin assignment





# CN751 (for communications)

| Pin No. | Name   | Level         |
|---------|--------|---------------|
| 1       | TxD IN | RS-232C level |
| 2       | NC     |               |
| 3       | NC     |               |
| 4       | RxD IN | RS-232C level |
| 5       | TD     | TTL level     |
| 6       | NC     |               |
| 7       | NC     |               |
| 8       | RD     | TTL level     |
| 9       | GND    |               |
| 10      | AF OUT |               |

Connector type: JST S10B-ZR-SM3A-TF

# CN701 (for FFC cable)

| Pin No. | Name    | Level |
|---------|---------|-------|
| 1       | GND     |       |
| 2       | GND     |       |
| 3       | KEY_AD0 |       |
| 4       | KEY_AD1 |       |
| 5       | KEY_AD2 |       |
| 6       | KEY_AD3 |       |
| 7       | KEY_AD4 |       |
| 8       | KEY_AD5 |       |
| 9       | KEY_AD6 |       |
| 10      | KEY_AD7 |       |
| 11      | NC      |       |
| 12      | Strobe  |       |


Connector type: Molex 52689-1240 FFC (0.5 mm)

# CN901 (for DC and video)

| Name              | Level                                                                      |
|-------------------|----------------------------------------------------------------------------|
| DC IN             | 6V to 12V                                                                  |
| GND (for DC IN)   |                                                                            |
| NC                |                                                                            |
| VBS OUT           | Composite video signal                                                     |
| GND (For VBS OUT) |                                                                            |
| Y-Out             |                                                                            |
| GND (For Y)       |                                                                            |
| C-Out             |                                                                            |
| GND (For C)       |                                                                            |
|                   | DC IN GND (for DC IN) NC VBS OUT GND (For VBS OUT) Y-Out GND (For Y) C-Out |

Connector type: JST S9B-ZR-SM3A-TF

# Strobe signal specifications



# **Precautions**

# **Software**

Use of the demonstration software developed by Sony Corporation or use of the software with customer developed application software may damage hardware, the application program or the camera. Sony Corporation is not liable for any damages under these conditions.

# Operation

Start the camera control software on your computer after you turn on the camera and the image is displayed.

# **Operation and Storage Locations**

Do not shoot images that are extremely bright (e.g., light sources, the sun, etc.) for long periods of time. Do not use or store the camera in the following extreme conditions:

- Extremely hot or cold places (operating temperature 0 °C to +40 °C (32 °F to 104 °F))
- Close to generators of powerful electromagnetic radiation such as radio or TV transmitters
- Where it is subject to fluorescent light reflections
- Where it is subject to unstable (flickering, etc.) lighting conditions
- Where it is subject to strong vibration

# Care of the Unit

Remove dust or dirt on the surface of the lens with a blower (commercially available).

### Other

Do not apply excessive voltage. (Use only the specified voltage.) Otherwise, you may get an electric shock or a fire may occur.

In case of abnormal operation, contact your authorized Sony dealer or the store where you purchased the product.